

# Biopel v9 PREMIUM

## User manual

---

Biopel pellet boilers are boilers fulfilling stringent requirements for ecological heating with low combustion emissions. It allows you to operate all electrical heating system components and connection of many types of additional devices operated by boiler control unit. You can find full list of possible accessories inside this manual. User manual includes all needed information about installation, startup and maintenance of all types of Biopel boilers, from 10 to 200kW of power. Information included in this manual are intended to both installer and end user. Chapters are written chronologically, starting with boiler installation, first start up and proper setup, to regular maintenance. Read all information included inside this manual carefully.

Each Biopel boiler can be connected to our online server to use remote control features for both boiler and heating system components. Online features are for free included in basic package of Biopel boilers. For more information, ask your supplier about how to connect your boiler to the internet.

We believe that you will be satisfied with our product for its long working life. For more information about this boiler and our company use not only this manual but also our network of representatives in your country as well as main staff of OPOP, Czech Republic.

---



# CONTENT

1. INTRODUCTION .....	4
2. BASIC DESCRIPTION OF BIOPEL LINE BOILERS .....	4
3. MAIN PARAMETERS .....	5
3.1. Biopel 10 - 40kW .....	5
3.2. Biopel 60 - 80kW .....	6
3.3. Biopel 100 - 200kW .....	7
3.4. Burner .....	8
3.5. Pellet tank .....	8
3.6. External feeder.....	8
4. BASIC COMPONENTS OF BIOPEL INSTALATION .....	9
4.1. Biopel 10 - 40kW .....	9
4.2. Biopel 60 - 80kW .....	10
4.3. Biopel 100 - 200kW .....	11
4.4. Burner .....	13
4.5. Pellet hopper.....	14
4.6. External feeder.....	14
5. INSTALTION PROCESS.....	15
5.1. Biopel 10 – 80kW .....	17
5.2. Biopel 100 – 200kW .....	18
5.3. Pellet tank .....	19
5.4. Burner .....	19
5.5. External feeder.....	20
5.6. Control unit v9 and connection board .....	20
5.7. Electrical connections .....	21
6. CONTROL UNIT v9 .....	24
6.1. Basic navigation .....	24
6.2. Main operation modes.....	25
7. CONTROL UNIT’S MENU LAYOUT.....	26
7.1. First start .....	26
7.2. Ignition / Extinction.....	26
7.3. Main settings.....	26
7.4. Fitters menu.....	28
7.5. Service menu.....	36
7.6. Language selection.....	38
8. FIRST START.....	39
9. COMBUSTION ADJUSTMENT .....	42
9.1. Flame parameters .....	42
9.2. Change fan speed.....	42

9.3.	Change operation time of external feeder .....	43
9.4.	Non standard installation.....	44
10.	HEATING SYSTEM EXAMPLES.....	45
10.1.	One CH circuit + DHW (trtermovalve) .....	45
10.2.	Two CH circuits + DHW(thermovalve) .....	46
10.3.	One CH circuit + DHW (4way valve) .....	45
10.4.	One CH circuits + DHW (čway valve + zone valve) .....	46
11.	REGULAR MAINTENANCE.....	49
11.1.	Biopel 10 - 80kW .....	49
11.2.	Biopel 100 - 200kW .....	50
11.3.	Burner 10 - 200kW .....	50
12.	BIOPEL ONLINE.....	51
13.	FIRMWARE UPDATE .....	51
14.	OPERATIONAL AND ALARM MESSAGES.....	52
15.	SOLUTIONS TO SPECIFIC SITUATIONS .....	53
16.	FACTORY SETTINGS .....	56
17.	WARRANTY CONDITIONS, GENERAL INFORMATION .....	58
18.	STANDARDS AND REGULATIONS .....	59
19.	WARRANTY CARD.....	60

## 1. INTRODUCTION

Read this manual step by step, each chapter from the beginning to the end, to make sure installation and start-up is made properly. You make sure your boiler runs at its best if you read all information included in this manual. Chapters describe first boiler installation, then chronologically accessories connection and activation and boiler maintenance. Manual describes all important steps and describes practical information for each chapter, so it helps customer to understand activity of all boiler and heating system components.

In the second half of this manual is full heating system examples including electrical components such as pumps and mixing valves and step by step description how to connect and activate these components inside v9 controller menu. Use this manual to connect and setup all accessories properly so boiler operation will be in accordance with user manual.

If you need more information about boiler function, do not hesitate to contact OPOP business partners in your country or directly OPOP staff. We will gladly tell you all the information you want to know.

## 2. BASIC DESCRIPTION OF BIOPEL LINE BOILERS

Biopel boilers are produced in several sizes, from 10 to 200kW. Boiler is operated by v9 control unit which regulates also all electrical components of heating system, if connected into the connection board in the front of the boiler. There are many advanced features implemented inside v9 controller which allows customer to use his boiler as he requires.

V9 controller allows following:

- 2 mixing valves operation.
- 2 room thermostats for 2 separate heating circuits.
- 5 pumps – central heating pump (CH pump), domestic hot water pump (DHW pump), valve pump 1, valve pump 2, additional pump with configurable settings.
- Weather compensation based on the outside temperature sensor.
- CH temperature time control - programmable weekly operation mode.
- Buffer tank operation with use of 2 temperature sensors.
- Online remote control by our OPOP online server: [opop.emodul.eu](http://opop.emodul.eu).
- iOS and Android applications to access and remote control your heating system
- Firmware update via USB key to upload new features.
- Additional output for boiler activation by solar heating device.
- DOE: detection of operation errors which checks boiler operation and informs you about any problems detected. DOE list can be accessed on the main screen or in Main settings, DOE/operation history.

Despite this, v9 controller allows connection of wide range of additional devices, which makes boiler operation and maintenance more automatic. List of all additional accessories is listed below:

- RT10 room thermostat, displaying information of full hydraulic system connection.
- Compressor cleaning of burner and heat exchanger, extending significantly intervals for manual cleaning.
- Automatic ash removal, extracting ash from bottom part of the boiler into the external container. You don't need to remove ash from the boiler too often if you install this device.
- Automatic exchanger cleaning, which moves turbulators inside the boiler up and down and cleans heat exchanger. All the ash drops down to the ashtray and can be removed automatically by automatic ash removal system.
- Lambda sensor, measuring remaining oxygen inside the boiler and adjusting combustion to make it more efficient.
- S8-Wifi, which regulates rooms in your home as separated zones with own temperatures to keep.
- GSM module, which can change boiler operation by sending sms messages on sim card inside this module.
- Vacuum transport, transferring pellets from external silo inside standard pellet tank next to the boiler.
- Cascade controller, allowing you to operate up to 4 boilers connected together and make big boiler rooms more efficient.
- Exhaust fan, to increase chimney draft if chimney is not high enough to support proper boiler operation.

These devices can be installed anytime, even after boiler installation. Ask your installer for more information about each accessories if you consider using these with your boiler. We will also gladly help you to explain and suggest possibilities how to make your boiler even more automatic and efficient.

### 3. MAIN PARAMETERS

Main components of basic installation are boiler, burner and fuel storage tank. You can find main parameters for each component down below, including also diameters and other important values.

#### 3.1. Biopel 10 - 40kW

Boiler body is always different according its maximum power. Main differences are external dimensions, connection outlets and inlets, flue gas outlet diameter, heat exchanger size and number of doors attached on the boiler body.

Technical parameters:		Biopel 10	Biopel 15	Biopel 20	Biopel 30	Biopel 40
Maximum power	kW	10,32	14,5	19,43	31,5	42,48
Minimum power	kW	2,99	3,7	4,7	8,5	11,4
Warranty fuel	Wood pellets 6-8 mm					
Fuel consumption (max power)	kg/h	2,5	3,4	4,4	7,2	9,96
Fuel consumption (min power)	kg/h	0,71	0,85	1,1	1,9	2,66
Emmision class * <sup>1</sup>	5					
Efficiency * <sup>1</sup>	%	89,94	91,4	92,82	92,2	91,41
Water volume	L	43		59,3		83
Recommended chimney draft	Pa	5-10	5-12	5-15	10-20	10-20
Maximum water pressure during operation	Bar	2				
Maximum water temperature in the boiler	°C	85				
Minimum return water temperature	°C	65				
Flue gas temperature (durning max. boiler power)	°C	70	73	77	87	97
Weight	kg	234	234	282	282	400
Supply voltage	V/Hz	230V/50Hz ±10%				
Dimensions:						
Boiler height	mm	1054				1154
Boiler width	mm	455		555		655
Boiler depth	mm	773		838		936
Flue gas outlet position from the ground	mm	708				808
Inlet water position from the ground	mm	178				
Outlet water position from the ground	mm	868				968
Counnecting diameters of water outlet and inlet	DN	G1 1/4"				
Flue gas outlet diameter	mm	130				150

\*<sup>1</sup> Emission parameters are measured according the EN 303-5 standards.

### 3.2. Biopel 60 - 80kW

Boiler body is always different according its maximum power. Main differences are external dimensions, connection outlets and inlets, flue gas outlet diameter, heat exchanger size and number of doors attached on the boiler body. Biopel 60-80kW can be installed only with external version of pellet tank.

Technical parameters:		BIOPEL 60	BIOPEL 80
Maximum power	kW	63,5	84,4
Minimum power	kW	15,5	19,96
Warranty fuel	Wood pellets 6-8 mm		
Fuel consumption (max)	kg/hod	15,1	20,1
Fuel consumption (min)	kg/hod	3,9	5,2
Emmision class *1		5	5
Efficiency *1	%	90,6	90,1
Water volume	l	95	130
Recommended chimney draft	Pa	10-15	
Maximum water pressure during operation	Bar	2	
Maximum water temperature in the boiler	°C	85	85
Minimum return water temperature	°C	65	65
Flue gas temperature (durning max. boiler power)	°C	117,8	131,9
Weight	kg	385	480
Supply voltage	V/Hz	230V/50Hz ±10%	
Dimensions:			
Boiler height	mm	1312	
Boiler width	mm	641	743
Boiler depth	mm	949	1049
Flue gas outlet position from the ground	mm	1007	1007
Inlet water position from the ground	mm	90	90
Outlet water position from the ground	mm	1171	1164
Counnecting diameters of water outlet and inlet	DN	G1 1/4"	
Flue gas outlet diameter	mm	150	178

\*1 Emission parameters are measured according the EN 303-5 standards.

### 3.3. Biopel 100 - 200kW


This size of Biopel has horizontal pipe type of heat exchanger. Its dimensions, way of installation and connection diameters of water inlet and outlet are also different than Biopel 10-80kW. Read exact values in the table below.

Technical parameters:		BIOPEL 100	BIOPEL 150	BIOPEL 200
Maximum power	kW	107,1	154,5	201,4
Minimum power	kW	28,7	44,5	59,9
Warranty fuel	Wood pellets 6-8 mm			
Fuel consumption (max power)	kg/hod	25,2	35,2	45
Fuel consumption (min power)	kg/hod	6,7	10,3	13,9
Emmision class * <sup>1</sup>		4	5	5
Efficiency * <sup>1</sup>	%	90,9	91,8	95,5
Water volume	l	690	950	1190
Recommended chimney draft	Pa	10-15		
Maximum water pressure during operation	Bar	2		
Maximum water temperature in the boiler	°C	85	85	85
Minimum return water temperature	°C	65	65	65
Flue gas temperature (durning max. boiler power)	°C	95,8	92,6	93,5
Weight	kg	1414	1740	2133
Supply voltage	V/Hz	230V/50Hz ±10%		
Dimensions:				
Boiler height	mm	1919		
Boiler width	mm	1560 / 1198		
Boiler depth	mm	1660	2060	2460
Flue gas outlet position from the ground	mm	1886		
Inlet water position from the ground	mm	606 / 70		
Outlet water position from the ground	mm	676 / 217		
Counnecting diameters of water outlet and inlet	DN	G 1 1/2" / G 2 1/2"		
Flue gas outlet diameter	mm	199		

\*<sup>1</sup> Emission parameters are measured according the EN 303-5 standards.

### 3.4. Burner

Pellet burner is different the same way as a boiler body, according to the maximum power. Differences are mainly in burner dimensions, types of electrical components and types of burner grates which are also different according to the burner size.



Dimensions mm	Biopel burner 10	Biopel burner 15	Biopel burner 20	Biopel burner 30	Biopel burner 40	Biopel burner 60	Biopel burner 80-100	Biopel burner 150-200
A	116	116	145	177	183	183	213	324
B	116,6	116,6	116,6	171	173,8	173,8	198,8	224
C	132	177	221	250,7	322,6	322,6	360,9	523,6
D	354	399	446,1	500	573	602	637	842,4
E	316,5	316,5	319,1	380,3	390,8	457,8	476,8	477,4
F	236	236	240	278	333	333	340	453
G	220	220	240	278	273	273	299	298
H	195	195	204	248	306	306	306	412
I	111,5	111,5	120	139	144	144	150	147,5
J	108,5	108,5	120	139	129	129	149	150,5
K	53	53	70,4	58,5	43	43	50	37

### 3.5. Pellet tank

Pellet tanks are divided to 2 main types. Compact version can be used with boilers from 10 to 40kW, external versions can be used for all Biopel types.

Pellet tank type	cm	External 60x60	External 80x80	External 100x100	External 1420x80	Compact big	Compact middle	Compact small
Volume of pellets	kg	110	220	300	350	250	150	60
Weight	kg	25	29	35	38	95	55	47
Height	mm	1300	1300	1300	1300	1210	1210	1210
Width	mm	600	815	1000	1420	653	507	507
Depth	mm	600	815	1000	815	1180	995	800

### 3.6. External feeder

External feeder is used only with external tank configuration. Compact tank has feeder already installed inside. You can choose two sizes – 2 or 3m length.

External feeder type	m	2	3
----------------------	---	---	---



## 4. BASIC COMPONENTS OF BIOPEL INSTALATION

Biopel is produced in several sizes depending on maximum power, from 10 to 200kW. Each size has its differences, speaking not only about dimensions, but also design of heat exchanger, doors, connection dimensions of inlets, outlets, flue gas outlets. Boiler size is also influenced by burner dimensions, pellet tank type which you selected, external feeder size and other. You can read about each main part of Biopel installation set below in next chapters.

### 4.1. Biopel 10 - 40kW

You can find 3 doors on the boiler. Two doors on the top of the boiler, one door in the bottom front part of the boiler. There is top lid on the top of the boiler for better isolation, which decreases the temperature loss. Cleaning doors on the top of the boiler are removable to get inside the heat exchanger easily, to clean the inside of the boiler without problem.

On each side there is place for pellet burner, covered on one side by metal flap. So you can choose from which side you insert pellet burner into the boiler. There is also attachment of motor for exchanger cleaning on the sides of the boiler and also connecting holes for control unit holder attachment if you use boiler with external type of pellet tank.


***i** Pellet burner can be installed on the right or left side of the boiler body.*

There are 2 inlets for temperature sensors on the back side of the boiler. Sink for CH and Termik temperature sensor is attached on the outcoming water outlet on the top back side of the boiler. On the bottom back side of the boiler is inlet for incoming water from heating system into the boiler. Next to this inlet is filling valve outlet to fill up boiler with system water. There are two covers on the back side of the boiler. First is placed next to the chimney flue path outlet, which covers lambda sensor and chimney temperature sensor connection. Second cover is at the bottom back side of the boiler for automatic ash removal motor (additional device). Chimney flue path outlet is positioned on the back side of the boiler as well. Temperature sensors (CH, termik and Chimney flue gas) re connected on the back side of the boiler. There are shafts for cables on the sides of the boiler.

On the bottom of the boiler there are adjustable legs, which can change the height of the boiler to keep it at horizontal level all the time. Hinges of the bottom front door are removable to make the opening of these doors on left or right side.

***i** Hinges of the bottom front doors are removable. You can install them on the other side and make to opening of the doors from other side.*

There is ashtray inside the boiler and above there are turbulators inserted inside heat exchanger. The reason is to keep the the heated air inside the boiler as long as possible, to increase boiler efficiency. Turbulators can be removed to access the heat exchanger easily and clean efficiently all the surface inside the boiler.



- a) Top lid, under combustion and cleaning top doors
- b) Sided bottom ash doors
- c) Adjustable legs on bolts
- d) Burner blanking flap on both sides of the boiler
- e) Blanking flap of aut. Exchanger cleaning
- f) External control unit holder (only with external pellet tank version)

- g) Inlet for CH and termik temperature sensors
- h) Inlet for filling / drain valve and for return water into the boiler
- i) Blanking flap for lambda sensor connection and chimney temperature sensor.
- j) Blanking flap for aut. ash removal system
- k) Hinges of top lid
- l) Closing handle for ash door
- m) Inlets for automatic heat exchanger cleaning

## Package content:

There are additional accessories inserted with mounting material inside the ashtray. Remove it for completing the installation. Amount and types of additional parts can vary depending on the type of the boiler.

- 3pcs of cleaning tools (brush, brush handle, scraper) – for cleaning the internal parts of the boiler.
- Filling valve – for filling water inside the boiler and draining if necessary.
- 2pcs of burner screws – installed on the burner outlet to hold the burner at right position.
- Ash container – in the bottom part of the boiler
- Burner flange (for 20, 30 and 40kW boiler) – installed on the boiler opening for the burner attachment.
- 4 screws of the burner flange (for boilers 30 and 40kW) - for mounting flange on the boiler opening for the burner attachment. Flange for 20kW boiler is attached directly on the burner screws.
- 2 pieces of wing nuts for burner attachment - to ensure the tightness between the flange and the burner. Mounted on the burner screws.
- 2 washers – placed on the burner screws, under the wing nuts.


## 4.2. Biopel 60 - 80kW

The boiler is equipped with three doors. Stoking, cleaning and ash doors. The top of the boiler is, for better insulation, fitted with a lid. Stoking and cleaning doors are fixed by wing nuts. Cleaning doors are also completely removable. On the sides, see the burner openings (left and right) and mounting for the control unit.



*Installation is possible only with an external type of pellet hopper.*

You see two main pipes in the rear part of the boiler. In the upper part of the back side of the boiler is outlet for outcoming water from the boiler, fitted with two sensors – CH and Termik. In the bottom rear part of the boiler is inlet for incoming water to the boiler, fitted with filling valve. Flue outlet and opening for the ash removal system (optional, only for 10-60kW) are also located in the rear side of the boiler.



- a) Top lid, underneath stoking and cleaning doors
- b) Ash door
- c) Boiler legs
- d) Burner openings on both sides
- e) Mounting for the control unit
- f) Outlet for outcoming water from the boiler, fitted with two sensors – CH and Termik

- g) Inlet for incoming water to the boiler, fitted with filling valve
- h) Connection of Lambda probe and the flue gas temperature sensor
- i) Opening for the ash removal system
- j) Upper lid hinges
- k) Ashtray door handle


## Package content:

There are additional accessories inserted with mounting material inside the ashtray. Remove it for completing the installation. Amount and types of additional parts can vary depending on the type of the boiler.


- 3pcs of cleaning tools (brush, brush handle, scraper) – for cleaning the internal parts of the boiler.
- Filling valve – for filling water inside the boiler and draining if necessary.
- 2pcs of burner screws – installed on the burner outlet to hold the burner at right position.
- Ash container – in the bottom part of the boiler. There could be one or two section ashtray.
- Burner flange – installed on the boiler opening for the burner attachment.
- Burner flange gasket - installed between the burner opening on the boiler and burner flange.
- 4 screws of the burner flange - for mounting flange on the boiler opening for the burner attachment.
- 2 pieces of wing nuts for burner attachment - to ensure the tightness between the flange and the burner. Mounted on the burner screws.
- 2 washers – placed on the burner screws, under the wing nuts.

### 4.3. Biopel 100 - 200kW

These boilers include a two-tier heat exchanger located in the upper part of the boiler. Exchanger pipes are located in a horizontal position above the opening for the burner installation. Exchanger tubes have 2 diameter sizes for better air flow in the boiler. In each of the tubes are turbulators, which are designed to reduce the temperature in the flue path so that the resulting boiler efficiency is maximized. Turbulators are removable for easier access to the heat exchanger during cleaning. For cleaning of heat exchanger tubes use the handle and plug brush, with which you can clean each of the exchanger tubes. Be sure to place the turbulators back into each of the tubes after cleaning. The purity of the heat exchanger is critical to ensure maximal heat transfer from the heated air into the water in the boiler and heating system.


 *Biopel 100 to 200 kW is equipped with two horizontal multilevel tube heat exchanger.*

Biopel 100-200 kW is equipped with two main doors, front and rear. Pellet burner is attached in to the opening which is on the front doors. Burner flange is attached to this opening as well. The burner is fitted into the hole with two burner screws and two wing nuts. Proper tightness is important for preventing leakage of air in the boiler or to prevent leakage of fumes from the boiler out. The door can be opened together with the burner for inspecting the inner parts of the boiler and burner grate without having to remove the burner of the boiler. To open the door with the burner you must dismantle the PVC hose between the burner and the feeder so that the external feeder doesn't stay in the way of door opening.

 **Caution: Never open the front door with a burner when the flame is in the boiler. For the flame inspection use always rear door.**

Front and rear doors are attached to the boiler using solid hinges and on the other side by closing handles. The tightness of the closure can be adjusted. Ensure tight closing of both doors and the correct adjustment of closing handles to prevent accidental opening of the door or leakage of smoke into the room through leaky doors closing. The front and rear doors are filled with flowing heating system water. Water is pumped through the door through the cooling hoses. Each hose is fitted with a ball valve. Doors can be separated from system water in the body of the boiler, if need of doors removal, repair etc.


In the upper part of the boiler are water inlet and outlet for connection of the boiler into the heating system. Smaller is inlet water to the boiler, bigger is outlet water from the boiler. Furthermore, the upper section provides outlet for flue gases. You can find an opening for connecting the Lambda sensor (optional) on the flue gas outlet.

 *Boiler handling is provided in two ways, either by increased base in the bottom of the boiler, or using a hoks in the upper part of the boiler.*

Inlet for filling valve is located on the side of the boiler, bottom part. When filling the boiler, check that all connections are sealed properly so water cannot leak out of the connections anywhere on the boiler. Especially check cooling hoses connections and do not forget to open all ball valves on each cooling hose so water can flow inside and outside the frontal and rear doors.

Electrical parts are installed in the front of the boiler (control unit v9 and connection board). There are also two outlets for temperature sensor installation (CH and Termik sensor) on the side of the boiler. All cables must be positioned so nothing can damage cables during operation of the boiler or when opening front or rear doors. It is also important that cables doesn't touch metal surface of boiler body (surface under the boiler covers) and that cables do not lay down on the ground without fixing. Hot ash can permanently damage electrical cabling. Make sure that cables are fixed on the position and cannot fall or move into the boiler when doors are opened. Bottom of the boiler is shaped so you can clean inside of the boiler easily. Use cleaning tools to remove all ash out of the bottom surface of the boiler. Clean all parts of the boiler

regularly and check ash content each day during first two weeks of operation. Quality of pellets directly influences how often you need to clean inside of the boiler (to clean heat exchanger, inside bottom of the boiler, flue path and burner). Set for your self how often is necessary to clean all mentioned parts according the real pellet consumption and ash creation during first two weeks of operation. Each boiler room is different. Check chapter *Cleaning* for more information about proper way of maintenance.



- |   |   |
|---|---|
| a) Frontal door                                   | j) Rear door  |
| b) Burner opening                                 | k) Cleaning door for flue outlet cleaning with ashtray inside |
| c) Cooling hoses with ball valves                 | l) Filling valve inlet  |
| d) Automatic exchanger cleaning                   | m) Flue gas outlet  |
| e) Bottom support for boiler handling             | n) CH water inlet   |
| f) Top support for boiler handling                | o) CH water outlet  |
| g) Inlets for CH and Termik temperature sensors   | p) Adjustable door closing mechanism                          |
| h) V9 control unit and connection board placement | q) Ball valves for each of cooling hoses                      |
| i) Lambda controller placement (accessories).     |   |

## Package content:

You can find following parts for boiler and burner installation inside the boiler. Content can vary considering exact boiler and burner size. Use these accessories for completing the installation and move on to the next chapter to start boiler properly.

- 3pc cleaning tools (brush, handle, scraper).
- Filling valve – for filling boiler with central heating water.
- 2pcs of burner screws – installed on the burner outlet to hold the burner at right position.
- Příruba hořáku – instaluje se na otvor hořáku.
- Burner flange – installed on the boiler opening for the burner attachment.
- 4 screws of the burner flange - for mounting flange on the boiler opening for the burner attachment.
- 2 pieces of wing nuts for burner attachment - to ensure the tightness between the flange and the burner. Mounted on the burner screws.
- 2 washers – placed on the burner screws, under the wing nuts.

#### 4.4. Burner

Pellet burner sizes vary from 10 to 200kW, each burner is different size. The difference between burners is not only the dimensions, but also different electrical components, grates, etc. Maximal burner power determinates also the external dimensions of each burner. Burner is attached by following components:

- a) internal pellet feeder (motor and spiral),
- b) fan,
- c) ignitor,
- d) fotosenzor,
- e) safety burner temperature sensor is indicating actual burner temperature,
- f) burner printed circuit board (burner PCB),
- g) removable grate,
- h) grenamatová plate (30-200kW),
- i) sealig cord,
- j) openings for burner screws attachment.

Burner pipe is connected on the top of the boiler and fixed by two small screws. There is also a sealing circle between the burner pipe and the burner. Two socets for control unit connection are located also on the top of the burner. Smaller socet is transferring signal of safety temperature sensor and fotosenzor. Bigger socket is for 230V power supply of all main electrical components on the burner (fan, motor and ignitor). Fan and motor is also connected to the capacitors which are responsible for smooth start of each of the components. Both condensators are attached on the burner.

Burner body and grate are stainless steel, so they can resist high temperatures inside the boiler reaching 1100°C. Burner grate can be removed for proper cleaning. Holes inside the grate should be always clean for best combustion quality.

**!** *Ignitor and sealing cord are consumable parts and must be changed in regular intervals.*


Ignitor provides automatic ignition, which takes from 3 to 5min. When flame is created, fotosensor detects light of the flame and boiler stansfers operation from ignition to PID work. Fotosensor together with safety burner temperature sensor are responsible for shutting down the boiler when burner temperature is higher than 60°C (safety temp. sensor is responsible) or when there is no flame inside the boiler (fotosensor is responsible).

Sealing cord must lay on the burner flange all around its surface, so no heat escapes from the burner outside. There is a high risk of damage when burner is not connected properly. Check the connection always, when burner was removed for cleaning or other service.

Burner is hearth of heating system and it needs proper regular maintenance. Pay high coughtion when you clean the grate and make sure that position of grate is as it should be. More information about cleaning and grate position is written in chapter *Regular maintenance*.

#### Package content:


- Burner 10 – 200kW
- Burner cover
- Burner pipe
- 2ks screws 4M, for burner pipe fixing
- Sealing circuit – for sealing the connection between burner and burner pipe.
- PVC hose – connect feeder and brner pipe
- Control unit v9 – attached on the side of the boiler oron the top of the compact hopper.
- 2ks wing nuts – for fixing the burner
- 2ks washers for burner screws



## 4.5. Pellet hopper

Two types of pellet hoppers are shown below. External and Compact versions. Compact hopper can be used with Biopel 10-40kW, External hopper can be used with all Biopel boilers. External hopper is assembled during boiler installation; Compact hopper is assembled in OPOP. Read chapter *Installation process* to see how to assemble External hopper properly.


Compact version is on the right side of the picture, all electrical components, including burner are hidden inside Compact hopper. External hopper is on the left side of this picture and is used only with 2 or 3m External feeders.



- |  |  |
|--|--|
| a) External hopper                                   | f) Compact hopper  |
| b) 3 legs  | g) Front door  |
| c) External feeder connection into the hopper        | h) Cleaning hole for removing the dust out of the hopper |
| d) Cleaning hole for removing dust out of the hopper | i) Cable shaft for electrical wiring                     |
| e) Filling opening – can be attached by cover        | j) Control unit v9                                       |
|  | k) Opening for burner installation on both sides         |

## 4.6. External feeder

External feeder is used to transfer pellets from external hopper into the burner. It is used only with external hopper. Compact hopper already has external feeder inside. External feeder is different type for each boiler power. Check the sticker on the external feeder to see, if it is the right speed for your boiler power. Use only external feeders for proper type of boiler.



- |  |   |
|--|---|
| a) Motor with capacitor – if your boiler you have, faster feeder you use | c) Feeder spiral                          |
| b) PVC pipe  | d) Pellet inlet into the feeder           |
|  | e) Pellet outlet to the burner            |
|  | f) 230V socket – or electrical connection |


## 5. INSTALTION PROCESS

Instalation process varies considering the boiler size, pellet hopper type. You can see full installation explanation down below. Choose your type of boiler and pellet hoper and read all information carefully.

Full installation process can be devidet to following sections:

1. Boiler, burner, hopper, and external feeder installation (chapters 5.1 to 5.6)
2. Accessoriess installation (chapter 5.7)
3. First start (chapter 8)
4. Combustion adjustment (chapters 9.1 to 9.3)
5. Accessories operational values adjustment (chapter 7)

Basic installation type can be devided by the type of pellet hopper. Basic component configuration varies by used pellet hopper. You can see first type of installation with compact pellet hopper. You can find burner, external feeder and control unit inside the tank when installation is finished. Picture below is also presented with additional accessories for better illustration of all possibilities which goes with Biopel boiler.



*Biopel set with compact version of pellet hopper*

- |   |   |
|---|---|
| a) Compact pellet hopper  | g) Control unit v9  |
| b) Front door   | h) Cleaning hole for removing the dust out of the hopper.                 |
| c) Filling opening  | i) Shafts for electrical cables.  |
| d) Accum transport (accessories)                                | j) Connection board for accessories connection is behind the front cover. |
| e) Burner opening from both sides (burner is inside the hopper) | k) Biopel 10 – 40kW   |
| f) Ash removal system (accessories)                             |   |

Compact hopper is not connected to the boiler by any means. It is placed next to the boiler and can be moved easily any time. When hopper is placed to the final position, next step is to attach burner inside the hopper. Open the front doors first. Hold the front doors and move them up by 2cm first. Then pull back to remove the door completely.

You can connect burner from left or right side of the boiler. Choose the opening on the same side of the hopper as on the boiler. Opening inside the hopper must be positioned properly on the burner opening to connect burner easily. Control unit v9 is placed on the top of the hopper and connected by cable to the connection board in the front wall of the boiler. Connect this cable into the connection board into the socket which is on the left side of the connection board. Use small oval openings which are on both sides of pellet hopper to move the cable from control unit to the connection board.

All cables connected into the connection boards can be held on the position by two fixing straps above the connection board.




There is external feeder inside the pellet hopper. Its outlet must be attached by PVC hose to connect external feeder and burner pipe. Connect cable into the External feeder socket for power supply.



**Caution: PVC hose must be installed in a way that pellets fall down to the burner without any problem. Otherwise you risk damage and back flame inside the hopper.**

There is cable shaft on both top sides of the hopper to move cables from the front to the back side of the installation set. Cover which protects the cables inside the hopper can be removed for easier cable installation. Cover must be placed back to cover electrical wiring against dust inside the hopper.

Second hopper version is external. External hopper can be used with all Biopel boilers from 10 to 200kW. However you have to use this type of hopper with Biopel 60 – 200kW always. You can see boiler with external hopper in the picture below. Presented set is also combined with additional accessories for better imagination what are the possibilities for biopel boilers.



*Biopel set with external version of pellet hopper*

- |  |  |
|--|--|
| a) External hopper                                   | h) Pellet burner   |
| b) Filling opening                                   | i) PVC hose  |
| c) External feeder connection to the hopper          | j) Burner pipe   |
| d) Cleaning hole for dust removing out of the hopper | k) Compressor cleaning (accessories)                     |
| e) External feeder (2 or 3m), 50° angle.             | l) Connection board behind the front cover of the boiler |
| f) Ash removal (accessories)                         | m) Biopel 10 – 200kW                                     |
| g) Control unit v9                                   |  |

External hopper is assembled during boiler installation. It is usually delivered disassembled in one box. External feeder is moved into the bottom leg of the hopper and fixed by chain to the top edge of the hopper. Check the angle of external feeder from the ground, which should be 50°. External feeder is connected to the burner with help of PVC hose. PVC hose must be straight so pellets can fall down easily to the burner. Connect power supply cable from connection board into the external feeder socket.

External hopper can be placed anywhere inside the boiler room, but you need to achieve no problem pellet supply from the hopper to the burner. Check all connection, proper PVC hose installation and make sure that PVC hose doesn't fall off the feeder or that PVC hose doesn't change its shape after some time.

External feeder motor has different speeds considering feeder type. For each burner power we have different feeder (motor) speed. Use only the external feeder which is for the same power as your boiler is.



## 5.1. Biopel 10 – 80kW

This is step by step explanation how to install all biopel boilers from 10 to 80kW of power. Read all information carefully and continue chronologically, so all important steps during boiler installation are met.

1. Open the covers and remove boiler from plastic protection. During boiler manipulation keep in mind that boiler has electronics inside. Make sure that:
  - a. If you move boiler with wooden protection, make sure that boiler covers are not damaged by wood or other parts of wooden covering. There are spikes inside the wood, so be careful to not damage the boiler during transportation.
  - b. Place boiler on straight floor with no deformation. Boiler must be placed horizontally, no angle is possible.
  - c. Make sure that there is enough space around boiler and hopper so you can move around the installation without problem.
  - d. Check if there is enough space to fully open ash doors and to remove ashtray out from the boiler without problem.

! *We recommend remove front boiler cover before any manipulation. Cover is not attached on the boiler with screws, it only hangs on the screws so be sure you do not damage this cover during boiler transportation.*

2. Remove all accessories out of the boiler. Cleaning tools are inside the boiler, connection material is in the ashtray.
3. Install filling valve on the outlet located in the back bottom side of the boiler.
4. Connect water outlet G1 1/4" to the heating system.
5. Connect water inlet G1 1/4" to the heating system.
6. Connect flue gas outlet to the chimney. Connection must be tight so no smoke escapes out of the flue pipe. Make sure that:
  - a. Chimney connection cannot decrease chimney draft below the minimal level mentioned in chapter *Main parameters*.
  - b. Chimney flue path diameter cannot be smaller than flue outlet on the back side of the boiler, so 130 or 178mm, depending on boiler type. Check mentioned value in chapter *Main parameters*.
  - c. Connection between flue outlet and flue pipe cannot hide lambda and chimney temperature sensors, located inside flue outlet on the back side of the boiler.
  - d. When connection into the chimney is finished, check and measure chimney draft to make sure that requirement for minimal chimney draft is met. If not we strictly recommend to install Chimney fan which is optional device to boost natural chimney draft.

! *Good chimney draft is very important for good combustion, proper ash creation and for smoke leakage prevention. If you see smoke leakage during operation, chimney draft is too low.*

7. Connect water hose on the filling valve and fill the boiler and full heating system with water. Check the maximal pressure, which should not increase above 2 bars during operation. So pressure should be lower when boiler is not active and system water is cold.
8. When boiler is filled, close the filling valve and remove water hose.
9. Check tightness of all pipe connections. If you detect some water leaking, repair it immediately, before you start the boiler.
10. Check proper position of both CH and Termik temperature sensors, which are inside the sink on the water outlet. Make sure they are fixed properly and there is no possibility for the sensors to fall off the sink.
11. Check inside of the boiler, mainly. Proper turbulators positioning inside heat exchanger, check burner flap below the stocking doors and check that there is no accessories left inside the boiler. Remove all parts which should not be inside the boiler during operation.
12. Check tightness of all doors. They can be damaged during boiler transportation. Sealing cords inside the doors must touch the boiler body all around properly, without any holes.
13. Choose the side where burner will be installed, left or right. On the other side should be burner cover, to close the opening for burner, if burner is connected from other side.
14. Proceed to the next chapter if all mentioned steps are done. Next chapter is about pellet hopper and burner installation. Read all information carefully to connect both parts properly.


## 5.2. Biopel 100 – 200kW

This is the installation procedure of Biopel boilers with outputs from 100 to 200 kW. The points below serve as a guide for installing the boiler to the heating system. Individual points are listed chronologically. Read therefore the points chronologically so you do not forget any of the fundamental points of the installation.

1. Unpack the boiler out of a paper protection. Remove transparent foil and place the body of the boiler to its final position in the boiler room. When handling the boiler consider following precautions:
  - a. When handling, be careful about the casing and other components of the boiler. The boiler can be moved only when the front and rear doors of the boiler are closed.
  - b. To manipulate boiler body use the trolley positioned under boiler, or crane with a chain attached from the top of the boiler. Boiler must be always in horizontal position during the transport procedure.
  - c. Place boiler on strait floor with no deformation. Boiler must be placed horizontally, no angle is possible.
  - d. Make sure that there is enough space around boiler and hopper so you can move around the installation without problem.
  - e. Check if there is enough space to fully open front and rear doors and to remove ashtray out from the boiler without problem (some boilers are not sold with ashtray).
2. Remove all accessories out of the boiler. Cleaning tools are inside the boiler, connection material is in the ashtray.
3. Install the filling valve on the inlet at the bottom side of the boiler.
4. According to the size of the boiler, filling valve is mounted on the lower side of the boiler, or placed as an accessory inside the boiler.
5. Connect water outlet G1 1/2" to the heating system.
6. Connect water inlet G1 1/2" to the heating system.
7. Connect flue gas outlet to the chimney. Connection must be tight so no smoke escapes out of the flue pipe. Make sure that:
  - a. Chimney connection cannot decrease chimney draft below the minimal level mentioned in chapter *Main parameters*.
  - b. Chimney flue path diameter cannot be smaller than flue outlet on the back side of the boiler, so 199mm. Check mentioned value in chapter *Main parameters*.
  - c. Connection between flue outlet and flue pipe cannot hide lambda and chimney temperature sensors, located inside flue outlet on the back side of the boiler.
  - d. When connection into the chimney is finished, check and measure chimney draft to make sure that requirement for minimal chimney draft is met. If not we strictly recommend to install Chimney fan which is optional device to boost natural chimney draft.
8. Install the cooling hoses with ball valves on the sleeves on the side of the boiler and on the front and rear doors. For clarity of cooling hoses connections, use image of Biopel 100 - 200kW in chapter *Basic components of biopel installation*.



**Caution: Ball Valves on each cooling hose must be set to open position. Otherwise you risk overheating.**

9. Connect water hose on the filling valve and fill the boiler and full heating system with water. Check the maximal pressure, which should not increase above 2 bars during operation. So pressure should be lower when boiler is not active and system water is cold.
10. When boiler is filled, close the filling valve and remove water hose.  
  
**Check tightness of all connections. Possible leakage must be repaired immediately or before boiler start up.**
11. Check the inside of the boiler, in particular: proper placement of turbulators in the heat exchanger, the correct position of the ashtray in the cleaning space (below the flue outlet) and make sure that there are no accessories or fasteners left inside the boiler.
12. Remove any parts that do not belong to the boiler.
13. Check the front and rear doors of the boiler. Check the correct settings of all closing handles, or adjust the position of hooks of closing handles that doors are tightly connected to the boiler body when closed.
14. If all points are met, you can proceed to hopper and burner installation.

### 5.3. Pellet tank


The compact pellet hopper installation is very simple since it comes from the factory already assembled. So unpack the hopper of the wooden cover, remove the foil and put the compact hopper in place next to the boiler side, where the burner will be assembled. Remove the burner opening cover from the boiler if necessary to install the burner, but do not forget to put this cover on the opposite side of the boiler to close the second burner opening (on the other side of burner position).

Be careful during hopper transportation, wooden cover is attached with spikes which can damage the hopper surface. We recommend to remove the cover first and then move the hopper. External hopper is assembled on the site, inside the boiler room. It comes disassembled from the OPOP factory. You can see installation procedure down below. Follow these steps carefully.

1. A and B connect together. You have part AB after connection.
2. Connect D with AB part. You have ABD part after connection.
3. Connect F with ABD part. You have ABDF part after connection.
4. Connect parts H, G, E a F with part ABDF.
5. Then, connect C with remaining hopper body.
6. Connect 3 legs onto the hopper body.
7. You are done. Move the hopper on the final position, next to the boiler and you are ready to connect external feeder.

If you are assembling 350kg external hopper, use additional plate (B type) to extend the standard 220kg hopper. So the installation procedure is the same as mentioned above only with one additional B type plate.

Check inside space in the hopper to make sure, there are no remaining parts, which should not be there during operation. Leave hopper empty so nothing other than pellets gets to the external feeder. Next step is burner installation. Read all steps to attach burner on the boiler body properly.



### 5.4. Burner

Type and burner size always vary depending the boiler size and power. Burner installation is therefore different considering the type of boiler and burner you use. Use this explanation as a general manual how to install burner the correct way. Full burner installation is divided to following steps:

1. Unpack all parts of the burner package out of the box.
2. Install the burner flange on the burner opening on the boiler (left or right side of the boiler), if the burner flange is part of the delivery (some boiler sizes doesn't use burner flange and burner is installed directly on the burner opening on the boiler body. Flange type varies according to the size of the burner and therefore the method of installation on the boiler is also different:
  - a. Biopel 10-15kW: no burner flange
  - b. Biopel 20kW: flange is attached to the 2pc burner screws.
  - c. Biopel 30-80kW: flange is installed using 4 screws M5, burner package includes frame sealing for the flange.
  - d. Biopel 100kW: flange is attached to the 2pc burner screws.
  - e. Biopel 150-200kW: no burner flange
3. Burner must be attached on 2pc burner screws, which should be mounted on the burner flange or directly on the burner opening on the boiler body (depends on mentioned boiler types above). Tighten this connection by 2pc wing nuts to make sure, that there is no space between the boiler and burner, so no air can leak out of this connection. Check the burner few times so it doesn't move when you push it up and down and tighten the wing nuts once again.
4. Done. If you moved the hopepr during burner installation, make sure that the pellet hopper is on its final position before you fill the hopper with pellets. Next step is External feeder installation, if you use Biopel with external hopper.

## 5.5. External feeder

External feeder installation must be done only if you use external hopper with your Biopel boiler. If this is your case follow explanation below to make sure feeder is installed properly. If you use compact hopper, skip this chapter and move to electrical connection of external feeder and other electrical components.

1. Remove the paper cover from the top of the external feeder.
2. Make sure that there is no damage of feeder spiral or of PVC tube inlet, where pellets go to the feeder. If there is visible deformation of PVC tube inlet, there is a risk that spiral get stucked by damaged or angled feeder inlet. In this case we do not recommend to install feeder with any visible damage.
3. Move the bottom leg of external hopper towards the burner so external feeder inlet can fit inside.
4. Move the external feeder inlet inside the hopper leg opening.
5. Top part of the feeder should be attached onto the top edge of external hopper by chain. Use small holes inside hopper legs to hang the feeder in right position.
6. Adjust chain length to make sure that external feeder is in 50° angle from the ground. If angle is smaller, feeder gives more pellets and the opposite. So if the angle is different, make sure you do proper combustion adjustment, described in chapter *Combustion adjustment*.



***Caution: Combustion adjustment must be done always, when external feeder angle is not 50°. Smaller angle means more pellets inside the burner – Fitters menu, Coefficients – make proper flame adjustment to correct the combustion!***

External feeder is on the place. Now you need to connect this feeder to the burner. Follow steps below.

1. Put burner pipe inside the burner top outlet. Do not forget to place sealing circle between the burner and burner pipe.
2. Fix this connection by 2pc bolts so the connection is tight.
3. Use PVC hose to establish connection between burner pipe and external feeder. You can cut the PVC hose to the length you need to make sure, that pellets can fall down to the burner without sticking inside the PVC hose.

## 5.6. Control unit v9 and connection board

External feeder is connected to the burner. Now we need to connect all cables to supply 230V to all electrical components. Following steps describe electrical wiring and control unit installation.

1. Remove front boiler cover. It hangs on two screws so move cover up by 2cm and then push towards you to remove the cover out of the boiler.
2. In case of compact tank, remove small cover on the side of the compact tank (side where burner and boiler is placed). You will use this opening to move cables from the connection board into the hopper.
3. Connect 230V AC power cord into the power supply socket.
4. Connect 230V AC power cord into the External feeder socket.
5. Connect burner cable into the burner sockets (2 sockets, small and bigger).
6. Connect control unit v9 into the connection board. There is a socket for this on the left top side of connection board. Place control unit v9 on the position (on the compact tank, or mount it on the side of Biopel boiler if you use external hopper version).

Basic electrical connection is finished. If you plan to connect additional devices into the connection board, use cable safts on the sides of the boiler to move cables from connection board to the back side of the boiler.



***Boiler cannot be in operation if any doors are opened. There is a risk that heat coming out of the opened door damages electrical wiring around the connection board. Make sure that cables do not touch hot surface of the boiler.***

Electrical connection for all additional devices can be found in next chapter. Now there is a time to connect all accessories which will be used with the boiler. When all electrical components installed, push ON button (red button on the connection board), close the connection board and put the front boiler cover back on its place on the boiler.

Before first start, read chapters *Electrical connections* and *Control unit v9*. This helps you to better understand control unit and the way how boiler is operated. These chapters will help you to understand all features of v9 control unit you will be able to navigate easily through the first boiler start up. First start should be the next chapter you should read to setup the boiler operation properly. Keep in mind that all the setup can be changed any time inside the menu structure of V9 control unit.

5.7. Electrical connections

Internet connection with RJ45 cable	RJ45	Valve 2	N
			L2
			L1
RS bus outputs for accessories connection (lambda, RT10, 431N, cascade, exhaust fan)	RS1	Valve 1	N
	RS1		L2
			L1
Additional sensor 4	C4	Additional pump	N
United output for C4,C3	GND		L
Additional sensor 3	C3	Valve 2 pump	N
Buffer sensor bottom	C2		L
United output for C2,C1	GND	Valve 1 pump	N
Buffer sensor top	C1		L
Solar contact	COM	DHW pump	N
	SOLAR		L
Room thermostat 2	ROOM REG. 2	CH pump	N
United output Room reg.1,2	COM		L
Room thermostat 1	ROOM REG. 1	Feeder 2	N
External (weather) sensor	EXTERNAL SENS.		L
Unitted uotput for weather and return temp. sensors	GND	Feeder 1	N
Return water sensor	RETURN SENS.		L
Valve sensor 2	VAL .2 SENSOR	Fan	N
United output for Valve 1,2 sensors	GND		L
Valve sensor 1	VAL .1 SENSOR	Heater	N
			L
DHW sensor	DHW SENSOR	Voltage free output	COM
			ON
Chimney temp. sensor	FLUE GAS SENSOR	Compressor 3	N
			L
Safety sensor Termik	THERMAL PROTECT	Deashing	N
			L
CH sensor	CH SENSOR	Vacuum transport	N
			L
Internal feeder temp. sensor (burner)	FEEDER SENSOR	Compressor 1	N
United output for burner and fire sensors	GND		L
Fotosenzor (fire sensor)	FIRE SENSOR	Compressor 2	N
			L

This is the list of all functions inside the control unit which are connected with each electrical output. Use this list for better orientation of accessories setup and activation. And also in case of alarm message, you can find easily which output is responsible for each alarm. It is simple to find the source of alarm with help of this list, for example when some temperature sensor is not connected but function inside the control unit connected with this sensor has been activated.

- **RJR5** – Fitters menu:
  - Internet module
- **RS1 and 2** – Fitters menu:
  - Lambda
  - Room thermostat
  - Additional valve 1 and 2
  - GSM module
  - Cascade.
- **Additional sensor 4 and 3** – Fitters menu:
  - For possible future use
- **Additional sensor 2 and 1** – Fitters menu:
  - Additional pump
  - Buffer tank
  - Build in valve 1,2 – Select CH sensor type
- **Solar contact** – Fitters menu:
  - Solar.
- **Room thermostat 1 and 2** – Fitters menu:
  - Room regulator – Regulator standard 1 and 2
  - Build in valve 1,2 – Room regulator – Regulator standard.
- **External (weather) sensor** – Fitters menu:
  - Built in valve 1 and 2 – Weather regulation
  - Weather sensor calibration
  - Firing up locked
- **Return water sensor** – Fitters menu:
  - Build in valve 1,2 – Return protection
- **Valve sensor 2 and 1** – Fitters menu:
  - Build in valve 1 a 2
- **DHW sensor** – Main settings:
  - Working modes – Water heater priority, Parallel pumps or Summer mode.
 – Service menu:
  - Disinfection – Disinfection temperature
  - Priority temperature
  - DHW hysteresis
- **Chimney sensor** – Service menu:
  - Max. temp. exhaust
- **Safety sensor Termik** – no associated function
- **CH sensor** – Main settings:
  - CH temperature
  - CH boiler weekly control
  - Working modes – House heating
 – Fitters menu:
  - Build-in valve 1,2 – Boiler protection
 – Service menu:
  - CH pump emergency activation
  - Boiler alarm temperature
  - Pump switch on temperature
  - Min. boiler temperature
  - Boiler hysteresis
- **Internal feeder temperature sensor** – Service menu:
  - Feeder alarm temperature
- **Fotosenzor** – Service menu:
  - Pellet settings – Ignition parameters – Firing-up brightness
  - Pellet settings – Operation parameters – Operation control

- **Mixing valve 2 and 1** – Fitters manu:
  - Build-in valve 1,2
- **Additional pump** – Fitters menu:
  - Additional pump
 – Service menu:
  - Pump switch on temperature
- **Valve pump 2 and 1** – Fitters menu:
  - Build-in valve 1,2 – Valve pump 1,2
- **DHW pump** – Main settings:
  - Working modes – Water heater priority, Parallel pumps or Summer mode.
 – Service menu:
  - Pump switch on temperature
  - DHW hysteresis
- **CH pump** – Main settings:
  - Working modes – Water heater priority, Parallel pumps or Summer mode.
 – Service menu:
  - Pump switch on temperature
- **Buffer sensors C1 and C2** – Fitters menu:
  - Buffer parameters
- **Internal (burner) feeder** – Service menu:
  - Internal feeder coefficient
  - Pellet settings – Ignition parameters – Feeder operations and Feeding pauses
  - Pellet settings – Damping parameters – Feed time and Feed interval
- **External (tank) feeder** – Service menu:
  - Pellet settings – Ignition parameters – Underpoor time
  - Pellet settings – Operation parameters – Min. power – Feeder operations and Feeding pauses
  - Pellet settings – Operation parameters – Max. power – Feeder operations and Feeding pauses
 – Fitters menu:
  - Coefficients – Min and Max feeder coefficients
- **Fan** – Main settings:
  - Burner cleaning
 – Service menu:
  - Pellet settings – Ignition parameters – Blow out time, Blow out gear, Fan rotations 1,2, Fan delay
  - Pellet settings – Operation parameters – Min. power – Min. working fan
  - Pellet settings – Operation parameters – Max. power – Max. working fan
  - Pellet settings – Operation parameters – Cleaning period
  - Pellet settings – Damping parameters – Fan rotations
 – Fitters menu:
  - Coefficients – Min and Max fan coefficients
- **Ignitor** – Service menu:
  - Pellet settings – Ignition parameters – Heater protection and Minimum heater power
- **Freely programmable output** – no associated function
- **Ash removal** – (Fitters menu) – Ash removal
- **Vacuum transport** – (Fitters menu) – Vacuum
- **Compressor 3, 2 and 1** – (Fitters menu) – Compressor 1, 2, 3


## 6. CONTROL UNIT v9

Control unit v9 is high resolution touch screen device. Type of the screen is properly selected in consideration of boiler room environment. It is covered by pelxi glass shield which protects it against dust and scratches. Control unit is connected into the connection board in front of the boiler by small plug and lay cable. Installation takes just few seconds. After boiler activation, by pushing main switch on the side of connection board, is v9 controller switched on and first procedure it takes is to check firmware versions of v9 controller and external board. Firmware versions are displayed below OPOP logo when you switch your boiler on. Those numbers should be the same for proper boiler operation.

Next step is to select your language. To do so, click on Menu button, and then navigate yourself to the right by clicking on right arrow key to display Language selection. Click on this button and select your language version. Translation is changed instantly. We recommend to read carefully next chapters to understand better the way how boiler and control unit v9 operates.

### 6.1. Basic navigation

Basic navigation is simple mainly because of touch screen, which simplifies usage of this controller. Read basic controller and Main screen description down below.



- a) Boiler temperature measured by CH sensor which is connected into the sink on the water outlet in the back of the boiler.
- b) Selected boiler temperature. Can be changed in Main settings, CH temperature. We recommend to set this temperature in range from 65 to 80°C.
- c) Real time operation state – Ignition, PID work or Extinction are the main phases of operation.
- d) Actual power in kW
- e) Pellet supply correction, made in Fitters menu, Coefficients.
- f) Burner temperature, inside the external feeder. Which should be from 15 to 55°C during PID work.
- g) Panel showing component real time operation, such as fan, feeders, ignitors, pumps and activated accessories.
- h) DHW temperature measured by DHW sensor, which is connected into the “DHW sens” output inside the connection board.
- i) Selected domestic hot water temperature. Can be changed in Main settings, DHW temperature. Works only when one of the DHW modes is activated in Main settings, Working modes.
- j) Display of pump operational modes. Can be changed in Main settings, Working modes. This is basically which of CH and DHW pumps has priority to start to operate first. Read Control unit’s layout structure for more information.
- k) Weather sensor temperature. Sensor is connected into the „Weather sens.“ output inside the connection board.
- l) Chimney temperature sensor. Should be in range from 70 to 110°C, by the size of the boiler.
- m) Flame detection by fotosensor. If you see this icon, flame is detected inside the boiler.
- n) Room regulator indication, if activated in Fitters menu, Room regulator.
- o) Real time and date.
- p) Menu button to access menu layout structure.
- q) Change main panel layout to display variety of information on the main panel. The possibilities vary depending on the number of accessories connected into the connection board. So you can display basic information about each accessory on the main panel.



## 6.2. Main operation modes

Biopel during its operation changes its phases according to request from user or automatic modulation. Each operation mode is displayed on the main screen. You can find more information about each operation mode down below, including sub steps made by control unit during each mode of operation.

**Ignition:** automatic ignition of pellets laid on the grate. Maximum time for ignition is set to 12min. Boiler goes through several stages during this operational mode:

- Pre-ventilation – grate cleaning by a fan, factory settings (hereinafter referred to as FS) = 30s.
- Underpore time – pellet dosing by feeders, the internal feeder in the burner operates twice as long as external feeder to move all of the pellets to the burner grate. FS = 12 – 15s
- Fan delay – preheating ignitor before starting the fan. FS = 30s
- Fan speed 1 – the fan speed during the first 6 minutes of ignition. The fan operates at low speed, to produce a flame, while not cooling down the ignitor. FS: 3-8%.
- Fan speed 2 – the fan speed during the second 6 min ignition. Maximum ignition cycle is 12 min. If pellets are not ignited within first 6min of ignition, fan will increase its speed to create a flame. The standard ignition time is 3-6 min. FS: 5-16%.
- Firing up delay – flame was created, fotosensor detects light, followed by stabilization of the flame procedure. If the flame detection by fotosensor is stable, boiler goes into PID work (normal operation). If the detection by fotosensor is not good and stable, boiler remains at the stage of Ignition, until the flame is not large enough. If the flame is not stable enough, it is followed by the second ignition (at least 12 additional minutes).
- The output of the phase Ignition may be:
  - Moving on to the PID work - normal operation of the boiler, or
  - The alarm message – Failed ignition, pellets failed for some reason to ignite. Boiler performs 2 tries of ignition before the announcement of this error condition appears. For more information, see chapter *Operating and error messages*.



**Caution:** the indicated time intervals and other values are set at the factory. But they may be changed in Service menu anytime.

**PID work:** normal operation of the boiler, indicated by current boiler power output and fan speed in %, which correspond to a percentage of current power in kW. The PID works following operating states are listed below:

- Min power – boiler starts its operation in the lower half of the power spectrum, from 0 to 50% of maximum power. The reason is to not damage small flame by incoming pellets after ignition. FS = 1-50% of maximal power, by the size of the boiler.
- Max power – burner is slowly increasing its power up to the maximal 100%. This can take from 5 to 15min. depending on burner size. Power modulation is influenced only by set and measured CH temperature.
- PID modulation – When measured CH temperature is close enough to the set CH temperature, burner starts to modulate power down to keep the CH temperature at level approximately  $\pm 5^{\circ}\text{C}$ . Set CH temperature can be overreached by  $5^{\circ}\text{C}$ , which is value set in Service menu, Supervision temperature. If CH temperature is higher for more than  $5^{\circ}\text{C}$  than desired CH temperature, boiler is turned off – extinction phase.
- The output of the phase PID work may be:
  - Transition to Extinction – set CH temperature is  $+5^{\circ}\text{C}$  or higher than set CH temperature.
  - Continuous PID work – set CH temperature is not overreached more than  $5^{\circ}\text{C}$  because of PID modulation. Burner will keep the flame inside and maintain CH temperature on levels around desired CH temperature. Power modulation will go up and down in time to keep the CH temperature at set level.
  - Off by room thermostat – room regulator can turn off the boiler any time, which causes boiler to go to Extinction phase. Desired room temperature has been reached.

**Extinction:** if measured CH temperature is higher than  $5^{\circ}\text{C}$  than set CH temperature, boiler goes to Extinction phase. Room regulator can force boiler to go Extinction as well when set room temperature has been reached. Boiler goes through following stages in Extinction phase:

- Cleaning – when there is still flame inside, fan speed is at 70% and external feeder is stopped to burn remaining pellets inside the burner.
- Cooling – when there is no flame inside, fan speed is 100% for several more minutes to clean the burner.



*When Extinction is finished, a „Stand by“ message appears. When CH temperature drops by  $15^{\circ}\text{C}$  or when room regulator sends signal to heat – ignition phase is activated again.*

## 7. CONTROL UNIT'S MENU LAYOUT

You can find full explanation of all functions inside v9 control unit. This list can be used as a general description for each feature to clearly understand how each feature works and which functions are connected between each other. Use this list in case, when you do not understand proper feature function. Keep in mind, that there is also full function description directly inside the control unit menu structure. Just hit "i" icon next to each function to display full description directly inside v9 controller.

### 7.1. First start


This is the first and most important setup, which has to be done immediately after activating the boiler for the first time. Only certified plumber can access this menu to setup all important parameters of boiler and its components. There is full chapter about First start. Read this chapter for more information on this topic.

### 7.2. Ignition / Extinction

These functions are responsible for manual start and stop of the boiler. You will see here Ignition, when boiler is deactivated and you will see here Extinction, when boiler is in operation. By pushing this button, you activate or deactivate the boiler. Keep in mind that you cannot force the boiler to stop or start, if room thermostat is connected and activated. Room thermostat has always priority, so you start and stop the boiler by changing required room temperature on the room thermostat directly.

### 7.3. Main settings

Content inside this setup is meant for final customer to change basic values without influencing critical parameters of combustion and safety features. However we advise you to change these values only when you are sure what will be the result of each change. Ask for advice before changing any value you do not understand properly.

<b>0. Max boiler power</b>	Reduce maximal boiler power. Only if "Feeder calibration" has been activated in Fitters menu.	25–100%
<b>1. CH temperature</b>	This option is used for setting the CH (central heating) boiler temperature. Recommended value is range from 60 - 80°C. Higher the temperature is, better for boiler life.	60–80°C
<b>2. DHW temperature</b>	Select desired DHW (domestic hot water) temperature. DHW heating is activated only if DHW temperature sensor is connected and Working mode in Main settings is properly selected.	45–70°C
<b>3. Burner cleaning</b>	Activation of burner fan for cleaning. Burner fan increases its speed in periods to clean the grate. This cleaning is semi automatic. Keep in mind that manual cleaning of burner is always required.	
<b>3.1 Cleaning period</b>	How often fan increases its speed to clean the grate. Bigger burner / more frequent cleaning necessary.	6-15min
<b>3.2 Fan operation time</b>	How long fan cleans. Bigger burner / longer time necessary.	10-20s
<b>3.3 Blow force</b>	Speed of the fan during cleaning. Recommended values: 50-100%. Bigger burner / faster speed necessary. Be careful about high burner speeds during cleaning interval. High speed (especially during minimum power) can cause extinction (no flame after cleaning). High fan speed can also cause unburned pellets to fall down to the ashtray. Adjust fan speed if you see situations like this.	50-100%
<b>4. Working modes</b>	Set operation mode of CH (boiler pump) and DHW (hot water production pump) pumps. Caution: pumps are activated only when measured CH temperature is higher than 40°C, which is set in Service menu, Pump switch on temperature. When heating DHW, DHW pump is started only when measured CH temperature is higher than measured DHW temperature, so DHW tank is not cooled down by colder CH temperature. Pumps operation is indicated by  icon on main panel.	
<b>4.1 House heating *1</b>	Only CH pump is active when CH temperature is higher than 40°C. No DHW production.	
<b>4.2 Water heater priority*2</b>	DHW pump is prior to CH pump. When set DHW temperature is reached - DHW pump is deactivated and CH pump starts to heat up the house. When measured DHW temperature drops below DHW hysteresis - CH pump is deactivated and DHW pump starts to operate until set DHW temperature is	

	reached again.. When heating DHW, DHW pump is started only when measured CH temperature is higher than measured DHW temperature, so DHW tank is not cooled down by colder CH temperature.
<b>4.3 Parallel pumps *2</b>	Both CH and DHW pumps work in the same time to heat up DHW tank and house as well. Pumps are activated only when measured CH temperature is higher than 40°C, which is set in Service menu, Pump switch on temperature.
<b>4.4 Summer mode *2</b>	Only DHW pump operates. CH pump is off constantly. If you use electric valve to heat up DHW tank instead of pump, you can activate CH pump during summer mode by Main settings, Working modes, CH pump summer.
<b>4.5 CH pump summer</b>	CH pump can be activated during Summer mode if electric valve has been used instead of regular DHW pump. In this case you have to maintain water flow during DHW production by CH pump.

\*1 Connect CH pump into the „CH pump“ output in connection board.

\*2 Connect DHW pump into the „DHW pump“ output in connection board.

<b>5. Hopper filled</b>	When activated, indicator of fuel level is set to 100% (visible on the main screen view). This indicates that pellet tank has been refilled. Important: to enable this feature, calibrate fuel consumption in Fitters menu, “Feeder calibration”.
-------------------------	---

<b>6. CH boiler weekly control</b>	The weekly regulation enables programming of ste CH temperature changes, each hour during the day and for each week day separately.
<b>6.1 Mode 1 (MIN-SUN)</b>	Activation of mode 1.
<b>6.2 Mode 2 (MON-FRI) (SAT-SUN)</b>	Activation of mode 2.
<b>6.3 Set mode 1</b>	Select desired CH temperatures for mode 1.
<b>6.4 Set mode 2</b>	Select desired CH temperatures for mode 2.

<b>7. DOE/Operation history</b>	Operation history, all boiler states and alarm situations are saved in this list. Also list of operation errors is included here with proper explanation what to do to remove this fault.
---------------------------------	---

<b>8. Disinfection</b>	Thermal disinfection applies to the DHW production and can be activated only in situation when DHW production is activated in Operation modes in Main settings. Thermal disinfection involves increasing the DHW temperature to necessary disinfection temperature (min. 60°C). You can change parameters of Disinfection in Service menu, Disinfection.
------------------------	---

<b>9.1 Screen settings</b>	Change all possible settings of how the main touch display behaves. You can change brightness, screen fade pause for lower power consumption, etc.
<b>9.2 Screen view</b>	Select one of two types of main screen view.
<b>9.2.1 Panel view</b>	Display main user information on main screen.
<b>9.2.1.1 Manufacturers screen</b>	Display service live parameters on main screen. Password required. Only for installers and advanced users.
<b>9.2.1.2 Screen brightness</b>	Change screen brightness when screen is active.
<b>9.3 Screen fade</b>	When screen is not used for 2min (value set in Screen view, “Damping time” feature), it goes to the low energy consumption state. Select the screen brightness for this state of function.
<b>9.4 Damping time</b>	How long it takes for the controller to proceed to the “Screen fade” state of operation.
<b>9.5 Sound of the alarm</b>	Activate and deactivate sound during the alarm situation.
<b>9.6 Sound of the buttons</b>	Activate or deactivate sound of buttons during controller's screen usage.
<b>9.7 Software update</b>	Firmware update procedure is mentioned in chapter <i>Firmware update</i> .

<b>10. Factory settings</b>	Reset all values in Main settings to the factory preset values.
<b>11. Software version</b>	Current program version. Module version - firmware inside main Connection board, Screen version - v9 touch controller firmware version.



## 7.4. Fitters menu

You can activate and adjust all accessories connected into the connection board. You can also adjust combustion settings for minimal and maximal burner power. Only installers and advanced users can change these values.

<b>1. Coefficients</b>	This feature allows you to correct combustion by changing fan speed and external feeder operating time. Use (+) and (-) to increase or reduce fan speed and external feeder run time for minimal and maximal burner power separately.
<b>1.1 Max. fan coefficient</b>	Correct fan speed for maximal power (100% of burner power). We recomend to do this correction when real burner power is at 100%.
<b>1.2 Min. fan coefficient</b>	Correct fan speed for minimal power (1% of burner power). We recomend to do this correction when real burner power is close to 1%.
<b>1.3. Forced minimal power</b>	By activating you force burner to operate only at minimal power. Use this function to adjust minimal flame size and quality of combustion. Do not forget to deactivate this feature when you finish minimal flame power correction.
<b>1.3 Min. feeder coefficient</b>	Correct feeder operation time during minimum burner power. We recomend to change it only if you see that the flame after ignition or when power is modulated down is too big or too small.
<b>1.4 Max. feeder coefficient</b>	Correct feeder operation time during maximum burner power. We recomend to change it when burner operates at 100% of its power.

<b>2. Feeder calibration</b>	To calculate proper pellet dosages, which matches your boiler power. Accessible only by certified technician under the code. Real boiler power is influenced by external factors, such as feeder angle and speed, pellet size and calorific value.
<b>2.1 On / Off</b>	Activate or deactivate Feeder calibration. Calibration is optional. If your installer does not activate Feeder calibration, we recommend to always do manual combustion correction in Fitters menu, "Coefficients".
<b>2.2 Calorific value of the fuel</b>	Calorific value of pellet. Pellet supplier can give you this number in MJ/kg or you can check your pellet bags. This number should be labeled on it.
<b>2.3. Tank capacity</b>	Set right size of you pellet hopper to display pellet content indicator on the main screen. Pellet content is calculated automaticly from Feeder calibration setup and it is displayed in %. When your pellet content is 0%, you need to fill the hopper again and push "Hopper filled" button in Main settings to display 100% of pellet content again.
<b>2.3 Weight fuel</b>	Set number of pellets measured in "Start weighing" function. Lower number, longer the feeder operation will be and the opposite – to supply exact numbers of pellets for power you need.
<b>2.4 Start weighing</b>	Activate feedr for 5min. Pellets fall down in to the bag which must be weightet after. Then insert the number in grams in "Weight fuel" function.

<b>3. Manual mode</b>	Start manually all electrical components to check proper function. Boiler will be turned off, if it is in operation phase.
-----------------------	--

<b>4. Room regulator</b>	Select type of room regulator which is connected to the Connection board. Select standard regulator which works on opened/closed circuit without voltage, or RT10 OPOP regulator. When room regulator activated, icons   indicates current state of operation on the main screen. When icon is red – room regulator sends signal to not heat. When icon is orange, room regulator sends signal to heat.
<b>4.1 Standard room regulator 1 *1</b>	Open/closed circuit typ of thermostat.
<b>4.2 Standard room regulator 2 *1</b>	Open/closed circuit typ of thermostat.
<b>4.3 Regulátor OPOP *2</b>	RT10 room regulator, connected to RS output inside Connection board.
<b>4.4 Firing up function</b>	When activated – room regulator turns boiler ON or OFF with no delay. When deactivated – boiler will decrease its CH temperature by number set in "Room reg. temp. lower" function when there will be no request for heating from room regulator.


<b>4.5 CH pump room regulator</b>	CH pump is operated by room regulator. If there is no request for heating, boiler and CH pump is deactivated. Always check real influence to the heating system when pump is deactivated to be sure there is not risk of overheating when CH pump is stopped.
<b>4.6 Room reg. temp. lower</b>	Boiler CH temperature decrease when room regulator sends signal to stop heating. "Firing up function" must be activated to use "Room reg. temp. lower" function. If set CH temp. is 70°C and Room reg. temp. lower is 10°C, boiler will be turned off when measured CH temperature reaches 70-10 = 60°C.

\*1 Thermostat standard 1, 2 connect into the „Room reg 1,2 and Com“ outputs inside connection board.


\*2 Regulator OPOP (type RT10) connect into one of two RS data outputs inside connection board.

<b>5. Lambda *</b>	To regulate combustion by measuring remaining oxygen inside the boiler.	
<b>5.1 First of time update</b>	Set the time of first oxygen correction. It takes some time for flame to stabilize itself after ignition so it is necessary to wait approximately 5min and then make first correction.	5min.
<b>5.2 Time of update</b>	How often lambda corrects the flame. This value should be around 5min. Bigger the burner size is the bigger the update time must be.	3-5min.
<b>5.3 Oxygen surge</b>	% of feeder operating time correction. This correction will apply each update time you have set in "Time of regular update" function.	2%
<b>5.4 Fan stroke</b>	% of fan operating speed correction. This correction will apply each update time you have set in "Time of regular update" function.	2%
<b>5.5 Sum</b>	When deactivated - Feeder and Fan corrections will be still the same (no increase or decrease after time). When activated - Feeder and Fan corrections will be +100% each "Time of regular update" until it reaches Min and Max correction which is the limit.	Yes
<b>5.6 Min. correction</b>	This is the minimal limit when Feeder and Fan corrections can go if "Sum" function is active. There is a risk, that lambda sensor will decrease boiler power if this value is too big. If this is the case and corrected flame by lambda sensor is small, you need to change this number closer to 0%.	-10%
<b>5.7 Max correction</b>	This is the maximum limit when Feeder and Fan corrections can go if "Sum" function is active. If flame is too smoky, black smoke coming out of the chimney, the % f correction is too big and lambda is forcing to supply too many pellets inside the burner. If this is the case, change this number closer to 0%. You have to check the lambda oxygen detection. If there is high level of oxygen inside the boiler during long period of time, there is some leakage on the boiler body where secondary air goes inside and increases oxygen level inside the boiler. Check tightness of all doors and connections on the boiler.	+10%
<b>5.8 Lambda 100%</b>	Excess oxygen measured by lambda sensor during maximal burner power. Lambda sensor is able to measure remaining (not burned) oxygen inside the boiler in range of +-1%. Short period peaks in oxygen measurement are normal, because of dosage of new pellets, chimney draft or because of burner cleaning by fan.	By the size of the burner
<b>5.9 Lambda 1%</b>	Excess oxygen measured by lambda sensor during minimal burner power. Lambda sensor is able to measure remaining (not burned) oxygen inside the boiler in range of +-1%. Short period peaks in oxygen measurement are normal, because of dosage of new pellets, chimney draft or because of burner cleaning by fan.	By the size of the burner

\* Connect Lambda module into one of two RS outputs inside connection board.

<b>6. Ash removal *</b>	Removes ash from the boiler to the ash container. Extends time for manual cleaning. Indicated by icon  on the main screen.	
<b>6.1 Operation time</b>	How long is the ash removal motor active. Works periodically. Number should be set from 5 to 20 min according to the burner size and number of ashes created. Bigger burner you have the longer operation time you need to clean all ashes.	5-20min
<b>6.2 Pause time</b>	How long it waits without operating. It depends on pellet quality and burner size. Number could be anything from 2 to 20 hours.	2-20h

\* Connect Ash removal into the „Deashing“ output inside the connection board.

<b>7. Compressor 1, 2, 3 *<sup>2</sup></b>	Compressor cleaning of burner or heat exchanger. Indicated by icon  on the main screen.	ON state	Off state
<b>7.1 On</b>	When activated, compressor is cleaning after extinction and during operation according to the time in "Pause time" submenu. When you clean during operation, burner loses its flame after compressor cleaning, so after 30s with no flame boiler goes to automatic ignition. For this reason we recommend to clean during operation only with big powers (80kW or higher) or if boiler is running without reaching set CH temperature, so it never stops.	On	
<b>7.2 Off</b>	When deactivated, compressor is cleaning only after extinction and it doesn't clean during PID work. Use this way of cleaning for smaller powers (10-60kW). Compressor will clean when boiler is stopped by room regulator or when CH temperature is reached. When extinction phase is completed, compressor starts to clean according to the values set below.		Off
<b>7.3 Cleaning period</b>	Total time of one cleaning period. Usually from 1 to 3 min, higher burner power longer cleaning period must be. During this period solenoid valve is opening and closing by set values in "Opening time" and "Cycle time" submenus.  If Compressor is set to ON, so it cleans also during PID work, we recommend to select this value to 1min max. If you have longer compressor cleaning than that, after 30s boiler goes to automatic ignition, because there is no flame inside the boiler, but there is still 30s left for compressor cleaning – so there is a risk that compressor will blow out all supplied pellets for ignition.	1min	3min
<b>7.4 Opening time</b>	"Opening time" of solenoid valve. Valve is opened periodically during "Cleaning period". Usually 1-2s.	2s	2s
<b>7.5 Cycle time</b>	Waiting time for next "Opening time" of solenoid valve. Each cleaning period the solenoid valve is opened (Opening time) periodically and "Pause time" is the waiting time for next opening (to pressurize the compressor again).	25s	20s
<b>7.6 Pause time</b>	Waiting time for another "Cleaning period". From 10 to 20 hours. This function works only during PID work, so only if compressor is On.	10-24h	We do not use * <sup>1</sup>

\*<sup>1</sup> Compressor if set to OFF works only after Extinction (when boiler is turned off). That is why we do not care about Pause time.

\*<sup>2</sup> Connect solenoid valve into outputs „Compressor 1 or 2 or 3“ inside connection board.

<b>8. Built in valve 1, 2 *<sup>1</sup></b>	Mixing valve operation for one heating circuit.	
<b>8.1 Valve OFF</b>	Deactivate valve operation.	
<b>8.2 Valve ON</b>	Activate valve operation.	
<b>8.3 Set valve temperature*<sup>2</sup></b>	Required valve temperature which is going to the heating circuit.	
<b>8.4 Calibration</b>	Calibrate the mixing valve if the operation is not as it should be. Movement from minimum to maximum opening.	
<b>8.5 Single stroke</b>	The length of one movement of mixing valve. Connected with "Measurement pause" function.	1-20%
<b>15.6 Min opening</b>	You can select minimum opening to achieve minimum water circulation in heating circuit. If you want to separate boiler from the heating circuit completely, select 0 in this function.	0-5%
<b>8.7 Opening time</b>	How long it takes to move the valve from minimum to maximum opening. It also depends on valve's parameters.	120s
<b>8.8 Measurement pause</b>	Pause between one stroke (movement). Control unit measures temperature periodically and makes the Single stroke action each time you set in this function. Connected with "Single stroke" function.	30s

<b>8.9 Valve type</b>	By changing valve type, max valve temperature is changed to protect the heating system against overheating.	
<b>8.9.1 Valve type CH valve</b>	Central heating valve. Maximum valve temperature is 85°C.	50-85°C
<b>8.9.2 Floor valve</b>	Floor heating valve. Maximum valve temperature is restricted to 55°C to protect damage of floor heating pipelines.	10-55°C
<b>8.10 Weather control *4</b>	Valve will be operated by external weather sensor. External sensor must be connected!	
<b>8.10.1 Heating curve</b>	Set equithermal operation by selecting heating curve in full range of outside temperatures. Valve temperature is changed automatically considering outside weather temperature. Valve temperature is changing automatically between these set points.	
<b>8.11 Room regulator</b>	Room regulator can influence valve operation. Select type of influence in this submenu.	
<b>8.11.1 Control without room controller</b>	Room regulator is deactivated. Room regulator has no influence to valve operation.	
<b>8.11.2 RS regulator decrease</b>	Room regulator RT10 is lowering valve temperature by set value in "Room reg. temp. lower".	
<b>8.11.3 RS regulator proportional</b>	Room regulator RT10 is closing or opening the valve considering actual request for heating from room regulator.	
<b>8.11.4 Standard room regulator</b>	Activate standard (open/close circuit) room thermostat 1 or 2.	
<b>8.11.5 Room reg. temp. lower</b>	Select temperature by which will be the set valve temperature lowered in case there is no request for heating from room regulator. It is connected with "Set valve temperature" and "RS regulator decrease" functions. "RS regulator decrease" feature must be activated to use this function.	
<b>8.11.6 Room temperature difference</b>	Room temperature hysteresis. By how much must room temperature drop to start heating again (opening the valve). Connected with "RS regulator proportional" or "Standard room regulator" functions. One of these two functions must be activated to use this feature.	
<b>8.11.7 Change in the set temp.</b>	In case of connection and activation of "Standard room regulator" feature, you can select the valve temperature decrease if there is no request for heating. Connected with "Set valve temperature" and "Standard room regulator" functions.	
<b>8.12 Propor. coeff.</b>	How often room regulator checks room and valve temperature and how often makes correction of current state to keep valve state in consensus with current setup.	
<b>8.13 Opening direction</b>	Direction of valve opening. It depends on the type of the mixing valve you use and on where you connected both L1 and L2 cables inside the connection board into the "Valve 1" or "Valve 2" outputs.	
<b>8.13.1 Left</b>	Mixing valve moves from right to left when opening.	
<b>8.13.2 Right</b>	Mixing valve moves from right to left when opening.	
<b>8.14 CO sensor selection</b>	Select sensor which works as a CH sensor. Connected with "Boiler protection function". Standard setup is "CH sensor" but you can change it for some special installations.	
<b>8.14.1 CH sensor</b>	CH (boiler temperature) sensor. It must be connected, or you will get an alarm message.	
<b>8.14.2 Additional sensor 1 *6</b>	C1 sensor. Sensor must be connected if you activate it, or you will get an alarm message.	
<b>8.15 Boiler protection</b>	Protect boiler against high CH temperature. Mixing valve will open and valve pump will push hot water out of the boiler if measured CH temperature is higher than selected value in "Max temperature" function.	
<b>8.15.1 Max temperature</b>	If there is higher temperature than set point, valve opens to push hot water out of the boiler. Valve pump will operate to push hot water out of the boiler until CH temperature is lower than set point.	85°C
<b>8.16 Return protection *3</b>	Use mixing valve as a return water protection to protect boiler against low temperature limit (risk of condensation inside the boiler). Return sensor must be connected or you get alarm message.	

<b>8.16.1 Off</b>	Return protection is deactivated. In this case there must be additional valve installed to protect boiler against low return temperature.	
<b>8.216.2 On</b>	Return protection is activated. Valve will be closed until valve temperature is higher than selected temperature in "Min. return temp." function. In this case you do not need to use any oadditional valve to protect boiler against low return water temperature, because this protection is maintained by mixing valve directly.	
<b>8.16.3 Min. return temp.</b>	Set minimum returning temperature to the boiler. Should be from 45 to 65°C. It depend on the max CH temperature which is going out of the boiler. The difference between CH and return temperature should be lower than 20°C. Minimal return temperature should be 50°C.	55°C
<b>8.17 Valve pump *5</b>	Valve pump operation can be adjusted in different ways to achieve exact way of operation you need. Possibilities of how to adjust the valve pump are listed down below.	
<b>8.17.1 Always ON</b>	Valve pump is always activated without stop.	
<b>8.17.2 Always OFF</b>	Valve pump is always deactivated	
<b>8.17.3 Always above the treshold</b>	Pump works if valve temperature is above the set point.	
<b>8.17.4 Switch on temperature</b>	Pump works when temperature is at set point or higher.	
<b>8.18 Factory settings</b>	Reset to the factory settings. All valve setup will be lost.	

\*1 Connect Mixing valves 1 or 2 into the „Valve 1“ or „Valve 2“ outputs inside the connection board.

\*2 Connect Valve sensors 1 or 2 into the „Val.1 sens.“ or „Val.2 sens.“ outputs inside the connection board.

\*3 Connect Return water sensor into the „Return sens.“ output inside the connection board.

\*4 Connect Weather sensor into the „External sens.“ output inside the connection board.

\*5 Connect Valve pump 1 or 2 into the „Valve 1 pump“ or „Valve 2 pump“ outputs inside the connection board.

\*6 Connect Additional sensor into the „C1 and Gnd.“ output inside the connection board.

<b>9. Valve 1, 2 *</b>	Mixing valve operation for one heating circuit with help of external 431N module.
------------------------	---

\*1 Connect 431N module into one of two RS data outputs inside the connection board.

<b>10. Buffer parameters *</b>	Select the way of buffer tank heat up.
<b>10.1 Buffer</b>	You can activate or deactivate buffer tank heating in this submenu.
<b>10.1.1 Off</b>	Deactivate heating of buffer tank.
<b>10.1.2 On</b>	Activate heating of buffer tank.
<b>10.2 DHW function</b>	Select the type of DHW production if buffer tank is ussed. Selection depends on exact heating system instalation.
<b>10.2.1 From buffer</b>	DHW production operated by DHW pump and buffer tank. Boiler will not be started, if there is higher measured temperature inside the buffer tank. So DHW will be heated by buffer tank not by the boiler. Boiler will not be started if temperature in buffer tank is higher than requested DHW temperature.
<b>10.2.2 From boiler</b>	DHW production is operated by DHW pump and boiler. Boiler will be started when there will be request for DHW production.
<b>10.3 Set temp. top</b>	The function enables the user to set the buffer's upper set temperature (the sensor should be placed at the upper part of the tank). After reaching this value, the pump deactivates (provided that also the buffer's bottom set temperature is reached).
<b>10.4 Set temp. bottom</b>	The option enables the user to set the buffer's bottom set temperature (the sensor should be placed to the bottom part of the tank).

\* Connect temperature sensors for buffer into the „C1“ and „C2“ outputs inside the connection board.



<b>11. Additional pump *</b>	Activation/deactivation of additional pump.
<b>11.1 Device type</b>	Select type of the pump.
<b>11.1.1 Pump deactivated</b>	Deaktivace přídavného čerpadla.
<b>11.1.2 CH pump</b>	Central heating pump operated by CH temperature sensor and Boiler hysteresis.
<b>11.1.3 DHW pump</b>	Domestic hot water pump operated by DHW temperature sensor and DHW hysteresis.
<b>11.1.4 Circulation pump</b>	Standard heating circuit circulation pump. Temperature can be selected in functions Max temperature, Min temperature, Sensor selection which operates the pump.
<b>11.1.5 Floor pump</b>	Floor heating pump behaves the same way as Circulation pump with one difference, maximum temperature of pump activation is decreased to protect floor heating system. Temperature can be selected in functions Max temp., Min temp., Sensor selection which operates the pump.
<b>11.2 Max temperature</b>	Max temperature in which Circulation or Floor pump is active.
<b>11.3 Min temperature</b>	Min temperature in which Circulation or Floor pump is active.
<b>11.4 Sensor selection</b>	Select sensor which operates Circulation or Floor pump. If you activate sensor which is not connected to the Connection board in front of the boiler, you get an alarm message.
<b>11.4.1 CH sensor</b>	CH sensor connected into the "CH sensor" output inside the connection board.
<b>11.4.2 DHW sensor</b>	DHW sensor connected into the "DHW sensor" output inside the connection board.
<b>11.4.3 Valve 1 sensor</b>	Valve sensor 1 connected into the "Valve1 sensor" output inside the connection board.
<b>11.4.5 Valve 2 sensor</b>	Valve sensor 1 connected into the "Valve2 sensor" output inside the connection board.
<b>11.4.6 Return sensor</b>	Return water sensor connected into the "Return sensor" output inside the connection board.
<b>11.4.7 Weather sensor</b>	Outside weather sensor connected into the "Weather sensor" outputs inside the connection board.
<b>11.4.8 Additional sensor 1</b>	Additional sensor 1 connected into the "C1" output inside the connection board.
<b>11.4.9 Additional sensor 2</b>	Additional sensor 2 connected into the "C2" output inside the connection board.

\* Connect Additional pump into the „Additional pump“ output inside the connection board.

<b>12. Ethernet module *</b>	Ethernet module enables remote control by our online services.
<b>12.1 Off</b>	Ethernet module is offline.
<b>12.2 On</b>	Ethernet module is online.
<b>12.3 Registration</b>	Get registration number to register your boiler online. This number is valid for 2 hours. If you do not finish registration within this time, you need to get a new number.
<b>12.4 DHCP</b>	The Dynamic Host Configuration Protocol (DHCP) is a standardized network protocol used on internet protocol (IP) networks for dynamically distributing network configuration parameters, such as IP addresses for interfaces and services.
<b>12.5 IP address</b>	An Internet Protocol address (IP address) is a numerical label assigned to each device (ethernet module) participating in a computer network.
<b>12.6 IP mask</b>	A subnetwork, or subnet, is a logical, visible subdivision of an IP network.
<b>12.7 Gateway address</b>	The gateway address (or default gateway) is a router interface connected to the local network that sends packets out of the local network.
<b>12.8 DNS address</b>	The Domain Name System (DNS) is a hierarchical decentralized naming system for computers.
<b>12.9 MAC address</b>	A media access control address (MAC address), also called physical address, is a unique identifier assigned to network interfaces for communications on the physical network segment.
<b>12.10 Module version</b>	Ethernet module firmware version.

\* Connect connection board with your modem or router by RJ45 ethernet cable.

<b>13. Modul GSM *</b>	GSM module is additional device which allows you to change basic parameters by sms and receive alarm messages on your mobile phone.
<b>13.1 Off/On</b>	Activation or Deactivation of GSM module.

\* Connect GSM modul into one of two RS data outputs inside the connection board.

<b>14. Cascade *</b>	Cascade controller is additional device which allows you to operate up to 4 boilers as it would be only one big boiler and use power of each boiler only when needed.
<b>14.1 Weather control</b>	Cascade operation is based on outside weather sensor. You can select from which outside temperature level your boilers starts to operate.
<b>14.1.1 Ekvitermní regulace</b>	Boilers are activated by external weather temperature. Lower the temperature is, more boilers will be in operation and the opposite.
<b>14.1.2 Modulation</b>	Cascade controller operates the boiler to achieve selected boiler temperature.
<b>14.2 Number of boilers</b>	Select number of boilers connected into the Cascade controller.
<b>14.3 Hysteresis</b>	Hysteresis is the boiler temperature drop when boiler should be started again. If boiler achieves its maximal CH temperature, it waits set temperature drop before it starts to operate again.
<b>14.4 Lower limit</b>	Minimal boiler CH temperature. If temperature is not reached during the time set in "Waiting time" submenu, next boiler is activated.
<b>14.5 Boiler 3 switch-on temperature</b>	Works with Modulation mode. CH temperature when selected boiler should be started.
<b>14.6 Boiler 2 switch-on temperature</b>	Works with Modulation mode. CH temperature when selected boiler should be started.
<b>14.7 Boiler 1 switch-on temperature</b>	Works with Modulation mode. CH temperature when selected boiler should be started.
<b>14.8 Waiting time</b>	Select time how long it takes to start second/third/ forth boiler if CH temperature is not reached during selected period of time.
<b>14.9 Version</b>	Actual firmware version of cascade controller.

\* Connect Cascade module into one of two RS outputs inside connection board.

<b>15. Exhaust fan *</b>	Select exhaust fan operation speed for min and max burner power. Exhaust fan modulates its speed according to the burner power and helps to boost up chimney draft. Fan speed modulation is automatic, inside the range you select.
<b>15.1 Min working fan</b>	Min speed of exhaust fan during minimal burner power.
<b>15.2 Max working fan</b>	Max speed of exhaust fan during minimal burner power.
<b>15.3 Version</b>	Actual firmware version of exhaust fan controller.

\* Connect Exhaust module into one of two RS outputs inside connection board

<b>16. Vacuum *</b>	Use vacuum transport to transfer pellets from silo to the boiler room.	
<b>16.1 Operation time</b>	Set how long vacuum transport works each day. Pellet hopper should be filled during this time, which usually takes 30min to 1h. We recommend to measure how long it takes to fill up the hopper in your exact situation and select the value according to that.	30min - 1h
<b>16.2 Switch on time</b>	Set the time when vacuum transport is activated during the day. Vacuum transport will then work for period of time set in "Operation time" submenu.	30min – 3h
<b>16.3 Switch on time 2</b>	Set the second time when vacuum transport is activated during the day. Use it if you need to fill up the pellet hopper more than once in a day.	30min – 3h
<b>16.4 Opening time</b>	Set how long it takes to fill up the vacuum container. It is one cycle of vacuum suction. It mainly depends on the PVC tube installation so check by yourself how long it takes to fill it completely. It takes approximately 80 to 200s.	80-200s
<b>16.5 Pause time</b>	Time when vacuum container flap is opened to release all pellets from vacuum container. We recommend to set 20s. Vacuum transport is then activated again and works for period of time set in "Opening time" submenu.  Electric switch on the vacuum container must be switched on by flap to make this system work again. If flap stays opened by the level of pellets inside the hopper, vacuum transport is deactivated and waits until pellet level drops down so the flap can close again and electric contact is switched on again.	20s


\* Connect Vacuum transport into the „Vacuum“ output inside connection board.

<b>17. Control from solar panel*</b>	Connect external device controlling solar panels for boiler activation/deactivation if there is or is not request for heatin by Biopel boiler. This contact is non voltage, based on closed/opened circuit.
<b>17.1 Control from solar (NO)</b>	Normal opened contact.
<b>17.2 Control from solar (NC)</b>	Normal closed contact.

\* Connect solar device into the „Solar and Com“ outputs inside connection board.

<b>18.1 Firing up lock *</b>	Select from which outside temperature, measured by outside weather sensor, should boiler start.
<b>18.2 Set temperature</b>	If there is lower outside temperature than set point, boiler will not operate untel the outside temperature increase above set point.

\* Friing up lock works only when external Weather sensor is connected into the „External sens.“ output inside connection board.

<b>19. External sensor correction*</b>	Correct external sensor measurement. Cable lenght can influence measured temperature value. Outside tempareture is measured by Weather sensor and displayed on the main screen next to  icon. T is used with Valve's weather operation features or with cascade controller.	
<b>19.1 Correction value</b>	Correct value to set proper temperature matching the real external temperature. Cable lenght can influence measured temperature value.	
<b>19.2 Averaging time</b>	Time of averaging all measured values when external sensor activated. This allows eliminating short peaks in outside temperature measurement, which can appear de to the outside weather conditions – wind, rain, sun, etc. Lower number – more data of outside temperature will be stored inside the memory. Higher number – the opposite.	30-100s

\* Connect external weather sensor into the „External sensor“ output inside connection board.

<b>20. Clock settings *</b>	Change actual time.
<b>21. Date settings *</b>	Change actial date.

\* Important for “CH boiler weekly control”, “Alarm history” and online features.


<b>22. Factory settings</b>	Do you want to reset all parameters form Fitters menu back to the factory values?
-----------------------------	---

## 7.5. Service menu

Service menu is used to adjust feeder operation and fan speed during maximal and minimal burner power. This menu is secured by password to make sure only certified plumber can access critical parameters for proper function of all electrical components of Biopel boiler. Only certified installer with OPOP permission can change these values.

<b>1. Pellet settings</b>	Change feeder and fan parameters for min and max burner power for all 3 main operation phases (ignition, work, extinction).	
<b>1.1 Ignition parameters</b>	Change parameters for ignition.	
<b>1.1.1 Blow-out time</b>	Cleaning interval before ignition. From 30s to 1 min. This feature is connected with "Blow by gear" feature.	30s
<b>1.1.2 Blow-by gear</b>	Speed of the cleaning before ignition. This feature is connected with "Blow out time" feature.	100%
<b>1.1.3 Underpoor time</b>	Dosage of pellets for ignition phase. Usually from 12 to 16s. It depends on burner size, chimney draft and pellet size. More pellets – longer time to create flame. However if there is not enough pellets (less than 12s), there is a risk of poor flame detection.	12-16s
<b>1.1.4 Firing-up delay</b>	Delay of feeder operation for ignition. It should be the same as "Blow out time" function. When fan stops cleaning feeder supplies pellets on the grate.	30s
<b>1.1.5 Feed time</b>	Internal feeder operation during ignition to supply remaining pellets on the grate during ignition. Usually 3min.	5s
<b>1.1.6 Feed interval</b>	Waiting time of internal feeder during ignition phase.	100-300s
<b>1.1.7 Fan rotations</b>	Speed of the fan during first half of ignition phase. Exact speed depends on fan type and it is from 1 to 8%.	1-8%
<b>1.1.8 Fan rotations 2</b>	Speed 2 of the fan during second half of ignition phase. Exact speed depends on fan type and it is from 3 to 16%.	3-16%
<b>1.1.9 Heater protection</b>	Maximum ignition time. 12min. Burner tries to ignite twice. If the ignition process is not successful (no flame) for the second time it shows alarm message "Heater error".	12min
<b>1.1.10 Firing-up brightness</b>	Sensitivity of fotosensor. Lower number means higher sensitivity. If photosensor sees the light even if there is no flame inside the boiler - increase the number to decrease the sensitivity. If photosensor doesn't see the light even if there is flame in the boiler - decrease the number to increase sensitivity. You can see real time light measurement on the left bottom corner of the screen. This number should be from 1000 to 5000 during PID work.	38
<b>1.1.11 Fan delay</b>	Fan operation delay to heat up the igniter. There is 30s waiting time from the ignition start to heat up igniter. After 30s fan is started.	30s
<b>1.1.12 Minimum heater power</b>	You can reduce heater power to extend its life. Be aware that low number can cause longer or not successful ignition.	0
<b>1.2 Operation parameters</b>	Change parameters of feeder and fan for PID work, at minimal and maximal power. Inside this range (min to max power) is fan and feeder operation changed automatically by PID work.	
<b>1.2.1 Min. power</b>	Change fan and external feeder operation during minimum burner power. Keep in mind that flame must be stable during this stage, so there is no risk of extinction or poor flame detection. If you make min. power flame too small, Burner cleaning can cause extinction and forced ignition because of that!	
<b>1.2.1.1 Max. feeding pause</b>	Maximum feeding pause during minimum burner power. Keep in mind that flame must be big enough so fotosensor can see the light. If the number is too big (long pause between dosages of pellets at minimal power), there is a risk of poor light detection.	7-25s
<b>1.2.1.2 Min. feeder operation</b>	Minimum operating time for the external feeder during minimum power of the boiler.	1-3s
<b>1.2.1.3 Min. working fan</b>	Speed of the fan during minimum burner power. If the speed of the fan is too fast at minimal power, there is a risk that flame will be destroyed by too fast fan speed. The number is usually close to 20% of fan speed.	5-30%

<b>1.2.2 Max. power</b>	Change fan and external feeder operation during maximal burner power. Flame must be orange, not aggressive. Dark, red flame - not enough oxygen (slow fan speed, too many pellets). Yellow, aggressive flame - too much oxygen (fast fan speed, not enough pellets).	
<b>1.2.2.1 Max feeder work</b>	Maximum operating time for the external feeder during maximum power of the boiler.	1-8s
<b>1.2.2.2 Min. feeding pause</b>	Minimum feeding pause for external feeder during maximum burner power.	7-25s
<b>1.2.2.3 Max. working fan</b>	Speed of the fan during maximum burner power.	10-70%
<b>1.2.3 Cleaning period</b>	Forced cleaning of the burner. When time set, boiler will stop operation and force Extinction phase. When extinction is finished, burner ignites pellets automatically again. It is good to activate this feature for bigger burners, such as 100-200kW. Recommended time is 20h.	0-20h
<b>1.2.4 Operation controll</b>	How often is the flame detection checked. If there is no light detected by photosensor during certain period of time, boiler goes from operation to Ignition automatically. Standard number is between 20 to 50s.	20-50s
<b>1.3 Damping parameters</b>	Change parameters for extinction.	
<b>1.3.1 Fan rotations</b>	Speed of the fan during extinction, to clean and cool down the grate.	50-80%
<b>1.3.2 Feed time</b>	Operation time of internal feeder during extinction to supply all remaining pellets on the grate.	5s
<b>1.3.3 Feed interval</b>	Pause time of internal feeder.	10-100s
<b>1.3.4 Damping time</b>	Maximum extinction time when there is flame detected by photosensor. If there is no flame control unit jumps to "Delay time" function to clean the grate.	5-10min
<b>1.3.5 Delay time</b>	This is cleaning and cooling of the grate after flame is gone. This time depends on burner size. Bigger burner you have longer the time must be. From 5 to 15min.	5-15min

<b>2. Max.temp exhaust</b>	Maximum temperature in the chimney flue path. If the temperature is too high, boiler reacts by decreasing the burner power. Actual chimney temperature is indicated by  icon on the main screen. Check recommended maximal chimney temperature of your boiler in chapter <i>Main parameters</i> .	220°C
<b>3. Feeder alarm temp</b>	Maximum temperature inside burner. 60°C set from the factory. If the temperature inside the burner is higher you get a "Feeder temp. too high" alarm message.	60°C
<b>4. Priority temperature</b>	This is maximal CH temperature when DHW production has been activated in Main settings, Working modes. To be sure, that hot CH temperature doesn't flow inside HW tank it is set, that CH temperature during DHW production is max 75°C. When "Priority temperature" (CH temp.) during DHW production is reached, boiler is turned off.	75°C
<b>5. CH pump emergency activation</b>	CH pump is activated during alarm status until CH boiler temperature doesn't drop below set point.	85°C
<b>6. Pump switch on temperature</b>	CH boiler temperature when pumps are activated. When CH temperature is lower than set point, pumps are deactivated to protect boiler against low temperature corrosion and to save some energy.	40°C
<b>7. Boiler alarm temperature</b>	Maximum boiler temperature, If the temperature is higher, alarm message "CH temperature too high" appears. When CH temperature is higher than set point, an "Boiler overheated" alarm message appears.	93°C
<b>8. Internal feeder coefficient</b>	Internal feeder works longer time than external feeder. The time extension is set in this function. Usually 100% longer operating time.	100-200%
<b>9. Fan</b>	Factory setup of the fan. No need to change this value. For producer only.	
<b>10. Min. boiler temperature</b>	Select minimal CH temperature which will be possible to select in Main settings, "CH temperature".	20-45°C

<b>11. Growth impulses</b>	Mosfet overheating protection. Factory value is 7. Mosfet is responsible for fan speed modulation. It can be overheated when for example fan is dirty and its rotation is not as it should be. This creates higher current in the mosfet and to protect the damage, a <i>"MOSFET temperature too high"</i> message appears on the screen. Higher number means faster reaction on mosfet overheating. 0 means this protection is deactivated. Check proper fan function whne this messige is shown	0-20
<b>12. Supervision temperature</b>	By how much can be the desired CH temperature overreached before burner goes to Extinction pahase and is stopped afterwoods. This feature is connected with "CH temperature" function in Main settings. Boiler is trying to keep CH temperature in range from desired CH temperature to +5°C whithout turning off. When set CH temperature +5°C is reached, boiler goes to Extinction.	5°C
<b>13. Boiler hysteresis</b>	CH temperature minus "Boiler hysteresis" means level of temperature when boiler is activated again. CH temperature = 75°C, Boiler hysteresis = 15°C. Boiler will be activated automaticly again when CH temp. drops below 60°C.	5-15°C
<b>14. DHW hysteresis</b>	DHW temperature minus "DHW hysteresis" means level of temperature when DHW pump/valve is activated again. DHW temperature 60°C, DHW hysteresis = 10°C. DHW pump/valve will be activated automaticly again when DHW temp. Drops below 50°C.	5-10°C
<b>15. Disinfection</b>	Forced increase of DHW temperature to disinfect bacterie inside DHW circuit.	
<b>15.1 Disinfection temperature</b>	Select temperature to which boiler increases its level to disinfect DHW heating circuit. Connected with "Disinfecion time" function.	75°C
<b>15.2 Disinfection time</b>	How long the DHW temperature stays increased. Connected with "Disinfection temperature" function.	10min
<b>15.3 Max. time of disimfection heating</b>	Maximal safety time of how long can be DHW temperature increased to selected value in "Disinfection temperature" function. If during set time is increased DHW temperature not reached, boiler returns to normal DHW production after finishing the maximal time of disinfection. This is a safety feature to make sure, tah DHW temperature doesn't stay increased for long period of time.	20min
<b>16. Boiler alarm min temperture</b>	Minimal CH boiler temperature which should be reached in time interval set in "Alarm time: temp. does not rise". If this CH temperaure is not reached during this time, ther will be an alarm message <i>"Temperature rise failed"</i> on the main screen.	30°C
<b>17. Alarm time: temp. does not rise</b>	During this time the minimal CH temperature set in "Boiler alarm min temperture" function must be reached. If the CH temperature doesn't reach selected value within specified time, you get alarm message <i>"Temperature rise failed"</i> . This is a boiler protection when for example there are no pellets inside the hopper, or other possible situations to double secure proper boiler function.	30min
<b>16. Factory settings</b>	Reset of all Service menu parameters to factory settings.	

## 7.6. Language selection

Change language by selecting "Languages" insi emnu layout of v9 controller. Main language is set to Eniglish from the factory, but you cen change l any time in this sub menu.

## 8. FIRST START

After successful installation of all electrical components and accessories there is finally time to setup the boiler and start it for the first time. You have to access First start menu to setup boiler properly so all main functions will work according to the burner and boiler power. First start menu is protected by password so only educated installers can access and setup main boiler features.



**Caution:** First start must be done when burner is deactivated, in extinction so there is no flame inside.  
You cannot do First start during ignition or PID work phases properly - values would not match your selection in First start menu.

Control unit will ask you step by step about basic information of the boiler and burner. When you finish your selection move to next question by pushing exit button.



*You have 30s for each question. If you don't make your selection in this time, control unit moves to another question after 30s of waiting time.*

For this reason we recommend to read diagram of First start below first and then do it in real time, so you will be informed about all the questions before you enter First start and you will spend less time thinking about each question. 30s interval is there to make sure that control unit doesn't stay in First start if you don't make any selection.



*Use all the information in first start diagram on the next page. This will help you navigate through the setup easily.*

- Set actual date and time – important for timer schedule functions, internet connection and also History of operation to see the alarm times properly.
- Burner power – select your burner size to save all the operational values of feeder and fan into the service menu setup. Check maximal burner/boiler size on the stickers which are placed on the side of the burner and on the back side of the boiler. Caution: wrong type of power selection can damage boiler or burner!
- Select CH temperature and Hysteresis – Central heating (CH) temperature is outputting boiler temperature measured by CH sensor. We recommend to set this temperature in range 65-80°C. Hysteresis is temperature drop when boiler is started again. Let say your boiler reached desired CH temperature and stopped. Hysteresis is responsible for repeated start of the boiler when CH temperature drops by selected value of Hysteresis.
- Select CH temperature above – by how much can be the set CH temperature overreached. Which makes the boiler modulation faster or slower. Standard number is 5°C.
- Next is the CH and DHW pumps activation, if connected into the connection board. Connect CH pump into the “CH pump” output and connect DHW pump into the “DHW pump” output inside the connection board. When DHW pump activated it is important to connect DHW sensor into the “DHW sens.” output or you get alarm message that sensor is not connected.
- Accessories activation in following order:
  - Room regulator – standard (non voltage version) connected into the „Room reg.1“ or „Room reg.2“ outputs) or RT10 which is OPOP regulator, connected into one of the RS data output inside the connection board.
  - Lambda sensor – connected into one of the RS data output inside the connection board.
  - Compressor 1,2,3 – connected into the „Comp1“ or „Comp2“ or „Comp3“ outputs. There is no difference between Compressor 1 or 2, both have same function. So it doesn't matter which one you choose to activate.
  - Vacuum transport, Ash removal, Exhaust fan – these you connect into the „Vacuum“, „Deashing“, “RS” data output.
- Mixing valve 1,2 – connect on „Valve1“ or „Valve2“ outputs. Caution: when valves activated, do not forget to connect Valve 1 or 2 temperature sensors into the „Valve1 sens.“ or „Valve2 sens.“ outputs, otherwise you get alarm message that sensors are not connected. If you use pumps for heating circuit operated by mixing valve connect each pump into the „Valve1 pump“ or „Valve2 pump“ outputs and activate directly inside Fitters menu, Build-in valve 1 or 2 sub menu.
- Next is basic explanation about how to clean the boiler, which components are important for boiler operation and what customer should know about the maintenance in general. Installer is responsible to tell these to customer.
- At the end of First start you will be asked to start the boiler for the first time. You can start the boiler manually any time inside the menu by pushing Ignition button. When started, boiler goes to ignition, which usually takes 5min to complete, then to the PID work.



*Keep in mind that most of the setup you do in First start can be changed any time in Fitters menu.*

You can change most of the values of First start any time in Main and Fitters menu. Next step (chapter) is about combustion adjustment, making sure that minimal and maximal flame parameters are correct. Move to the next chapter.

## 9. COMBUSTION ADJUSTMENT

After Ignition phase activation wait until pellets are ignited automatically and boiler changes its operational status from ignition to PID work. When there is a flame, boiler modulates power up to the maximum value set in First start settings. Wait until burner power is at maximum, indicated on the min screen by kW and speed of the fan is Po aktivaci kotle (Roztápění) počkejte, % also visible on the main screen under fan icon. Now there is time to open top door and look at the flame. Check quality of combustion and flame parameters by description below. Keep in mind that also quality of pellets, chimney draft, incoming air inside the boiler room and other external factors influences combustion quality and ash creation. If you use Biopel boiler with lambda sensor, flame adjustment is automatic after lambda sensor activation.

Keep in mind, that quality of combustion highly depends on pellet quality, proper chimney draft. If these requirements are not met, combustion quality will drop significantly.

### 9.1. Flame parameters

Flame type coming from the burner can almost certainly determine whether the combustion process is optimal, or whether it is necessary to make a correction. Examples of good and bad combustion processes are listed below.

#### **Ideal flame at 100% power:**

- The maximum length depends on the size of burner (it may be affected also by chimney draft and type of pellets).
  - boiler 10-15kW = about 25-30 cm from the end of the grate
  - boiler 20-30kW = about 35-45 cm from the end of the grate
  - boiler 40-80kW = about 50-70 cm from the ends of bones
  - boiler 100-200kW = approx 80 to 120 cm from the end of the grate
- The yellow-orange color of flame, unburned pellets do not fall out of the grate, only soft ash inside ashtray.

#### **Incorrect flame at 100% power:**

- The maximum length of the flame is less than or greater than dimensions mentioned above.
- Flame colour is light yellow (to fast fan speed) or dark orange to red (to slow fan speed).
- Unburned pellets fall into the ashtray, dark smoke comes out from the chimney.

#### **Ideal flame at 1% power:**

- Flame must be big enough, so fotosensor detects the flame with no problem. To check flame detection look at the flame icon in top right corner of main screen.
- Or you can go to Service menu, Pellet settings, ignition parameters, Firing up brightness and check the live value detected by fotosensor in left bottom corner of the screen. The numbers during min power should be moving from 500-3000, not lower. If the number is lower, flame is too small or fotosensor is not cleaned.

#### **Incorrect flame at 1% power:**

- Flame is too small and unstable so fotosensor doesn't detect the flame correctly. Increase the flame size by following parameters.

Use following functions to correct the flame. Whole combustion process can be influenced by fan speed and external feeder operation and you can do so always for minimal and maximal power separately. Inside this range (from min to max) is fan and feeder operation corrected automatically by PID work considering measured and selected CH temperature.

### 9.2. Change fan speed

To change fan speed use "Min. fan coefficient" and "Max. fan coefficient" features in Fitters menu, Coefficients. Use "forced minimal power" feature to force burner to run constantly at minimal power to adjust min. power flame. Make these corrections if you see flame with following parameters:

#### **Decreasing the numbers (minus values):**

- Flame is too aggressive and creates sparkles
- Fan is pushing unburned pellets out of the grate
- Flame is too small and aggressive

#### **Increasing the numbers (plus values):**

- Flame is slow and dark red
- There is a lot of dark ash and badly burned pellets on the grate
- Flame is too big and smokes



### 9.3. Change operation time of external feeder

If fan correction is not enough to keep the flame at desired parameters, use feeder coefficients to change number of pellets for minimal and maximal power. Go to Fitters menu, Coefficients and use a “Minimal feeder coefficient” and “Maximal feeder coefficient”. Use “Forced minimal power” feature to force burner to run constantly at minimal power to adjust min. power flame. Make these corrections if you see flame with following parameters:

Decreasing the numbers (minus values):

- There is too much black ash on the grate
- Flame is too big and smokes dark
- Chimney temperature is higher than recommended

Increasing the numbers (plus values):

- Boiler is not able to heat to desired CH temperature
- Flame is too small and aggressive.
- Chimney temperature is lower than recommended.

Wait 5min after each correction and check new flame parameters after. Each correction takes at least 5min to be visible on the flame itself. If you are not satisfied, make correction again until min and max flame size is as it should be.

Keep in mind that boiler must run at stable min or max power to really see how the flame looks like at this (min or max) stage of operation. If CH temperature is not reached, boiler will run at maximal 100% of power – this is the time to do max power flame corrections. To make min power flame corrections, use “Forced minimal power” feature in Fitters menu, Coefficients.



*Do not forget to turn off “Forced minimal power” feature when you finish with min flame corrections. Otherwise boiler will run only at min power.*

In case of non standard installation, use following advices to make sure the combustion at min and max power is as it should be. Follow explanation inside next subsection.

### 9.4. Non standard installation

Your installation should be as close as possible to recommended parameters listed below. These points must be considered especially in case of external tank usage.

- External feeder type (speed of the feeder) for proper boiler size. Each boiler, burner and external feeder is labeled by sticker. On this sticker you can always see for what power is this component meant to be. So if you use external feeder, check the sticker to be sure you use feeder for proper boiler size. There are several external feeder types with different motor speed, so make sure you use proper model for your boiler.
- External feeder ground angle should be 50°C
- Chimney draft should be 15Pa
- Pellet size should be 6mm. If you use 8mm pellets make sure you adjust flame parameters for minimal and maximal burner power as mentioned above.

If one or more of points above are not met, keep in mind you have to do proper flame adjustment as mentioned above to make sure that:

- Flame at maximal power is big enough to give you proper power. Combustion is good enough to create soft ash made by only small particles. No black smoke is coming out of the chimney. Flame has yellow to orange color.
- Flame at minimal power is stable, so there is no risk of unexpected loss of flame. Photosensor detects the minimal power flame properly (flame icon on the main screen is not disappearing).

In this case certified plumber can use “Feeder calibration” option in Fitters menu, to calculate exact dosages of pellets which is needed to achieve requested power. This setup alters factory settings of feeder operation for minimal and maximal power in Service menu.




*Use certified plumber or OPOP staff members to get more details on how to adjust the flame after commissioning.*

Boiler is properly set up. All necessary procedures are finished. We recommend to read chapter about boiler and burner cleaning as a next.

## 10. HEATING SYSTEM EXAMPLES

The most used heating system installations are listed below. This description includes full explanation of how to connect, activate and setup all electrical components of your heating system inside v9 control unit menu structure.

### 10.1. One CH circuit (3-way thermostatic valve) + DHW (DHW pump)




**Basic connection with one circuit of central heating (operated by CH pump) and one circuit of hot water (operated by DHW pump):**

- Boiler protection against low-temperature corrosion by a thermostatic valve (50 ° C and higher).
- Boiler control according to the set CH temperature (60°C or higher) and a DHW temperature (by customer's setup).
- All control elements and accessories are connected into the connection board, placed in front part of the boiler.
- Connect CH pump into the connection board (CH pump output).
- Connect DHW pump into the connection board (DHW pump output).
- Connect DHW sensor into the connection board (DHW sensor output).
- Check correct connection of CH sensor, which is inside the sink on the water outlet on the back side of the boiler. There should be no risk of losing the sensor and falling down out of the sink.
- Set maximal CH temperature in Main settings, CH temperature.
- Set maximal DHW temperature in Main settings, DHW temperature.
- Activate "Water heater priority" in Main settings, Working modes.
- Boiler will heat the domestic hot water tank as a priority according to the preset DHW temperature (DHW pump is turned on as a first until set DHW temperature is reached).
- Caution, DHW pump will be activated only if CH temperature is higher than actual DHW temperature to be sure that colder CH temperature isn't cooling down DHW tank.
- When set DHW temperature is reached, DHW pump is deactivated and CH pump is activated to maintain circulation of water inside heating system and to protect boiler overheating.
- CH or DHW pump will be activated only if measured CH temperature is 40°C or higher. Value set in service menu, "Pump switch on temperature".
- DHW pump will be activated again when DHW temperature drops by number set in Service menu, "DHW hysteresis". When DHW pump activated, CH pump is deactivated and the opposite.
- Connect room regulator into the connection board, into the "Room regulátor 1 or 2" (standard open/close thermostat), or "RS" (RT10 thermostat) outputs. Depending on the type of thermostat you use.
- Activate room thermostat in fitters menu, Room regulator – "Standard room regulator" or "regulator OPOP". Depending on the type of thermostat you use.

- Set type of rection on room regulator signal. Room thermostat can turn on/off the boiler immediately or it can decrease CH temperature by set level:
  - Immediate off/on boiler by room regulator:
    - Activate “Firing up function” in Fitters menu, Room regulator.
    - In case you want to deactivate CH pump in the same time as boiler by room regulator, activate “CH pump room regulator” function in Fitters menu, Room regulator. Be careful about the possibility of overheating when CH pump is deactivated!
  - Lowering set CH temperature by room regulator:
    - Deactivate “Firing up function” in Fitters menu, Room regulator.
    - Set level of CH temperature decrease when no request for heating from room regulator by “Room reg. temp. lower” in Fitters menu, Room regulator.
    - Set maximal CH temperature is now lowered by this value. So boiler will modulate power down sooner and it will also achieve maximal CH temperature sooner.
    - This type of regulation is recommended for bigger heating systems with lot of water volume inside. So boiler is not turned off by room thermostat too often and it takes less time to heet up the system again when roo thermostat requires heating again.
- Boiler will heat up DHW tank even in situation when room thermostat sends signal to stop heating. DHW production is not connected with room regulator’s requests for heating.

## 10.2. Two CH circuits (3-way thermostatic valve) + DHW (DHW pump)



**Connection with two heating circuits for central and floor heating (operated by mixing valves 1, 2 valve pumps 1, 2) and one circuit of hot water (operated by DHW pump):**

- Boiler protection against low-temperature corrosion by a thermostatic valve (50 ° C and higher).
- Boiler control according to the set CH temperature (60°C or higher) and a DHW temperature (by customer’s setup).
- All control elements and accessories are connected into the connection board, placed in front part of the boiler.

### Pump connection:

- Connect CH pump into the connection board (CH pump output).
- Connect DHW pump into the connection board (DHW pump output).
- Connect Valve 1 pump (for CH) inside the connection board into the “Valve1 pump” output (CH pump for radiators heating).
- Connect Valve 2 pump (for FH) inside the connection board into the “Valve2 pump” (FH pump, for floor heating).

**Temperature sensors connection:**

- Connect DHW sensor into the connection board (DHW sensor output).
- Connect Valve 1 sensor (for CH) inside the connection board into the "Valve1 sens." output.
- Connect Valve 2 sensor (for FH) inside the connection board into the "Valve2 sens." output.
- Connect Return temperature sensor on the water inlet close to the boiler and connect it inside the connection board into the "Return sens." output.
- Connect Weather temperature sensor inside the connection board into the "Weather sens." output.
- Check correct connection of CH sensor, which is inside the sink on the water outlet on the back side of the boiler. There should be no risk of losing the sensor and falling down out of the sink.

**Mixing valves connection:**

- Connect Valve 1 (for CH) inside the connection board into the "Valve1" output.
- Connect Valve 2 (for FH) inside the connection board into the "Valve2" output.

**Room regulator connections on each heating system (CH and FL):**

- It is necessary to connect one thermostat for each heating circuit (CH and FL). Room thermostat will operate mixing valves temperature accordingly to the current requests from room thermostat.
- Connect room thermostats inside the connection board into selected outputs "Room regulator 1 or 2" or into "RS" output if you use RT10 room regulator.
- Keep in mind that you can use only one RT10 regulator with each Biopel.
- We will activate and setup each thermostat later.

**Sat basic temperatures:**

- Select CH temperature in Main settings, "CH temperature".
- Select DHW temperature in Main settings, "DHW temperature".

**DHW activation:**

- Activate "Water heater priority" in Main settings, Working modes.
- Boiler will heat the domestic hot water tank as a priority according to the preset DHW temperature (DHW pump is turned on as a first until set DHW temperature is reached).
- Caution, DHW pump will be activated only if CH temperature is higher than actual DHW temperature to be sure that colder CH temperature isn't cooling down DHW tank.
- When set DHW temperature is reached, DHW pump is deactivated and CH pump is activated to maintain circulation of water inside heating system and to protect boiler overheating.
- CH or DHW pump will be activated only if measured CH temperature is 40°C or higher. Value set in service menu, "Pump switch on temperature".
- DHW pump will be activated again when DHW temperature drops by number set in Service menu, "DHW hysteresis". When DHW pump activated, CH pump is deactivated and the opposite.

**Activation and setup of mixing valve 1 (for CH):**

- Activate Valve 1 (for CH) in Fitters menu, Build-in valve 1.
- Set valve 1 temperature in Fitters menu, Build-in valve, Valve temperature.
- Mixing valve will keep this temperature in the set level. In case of reaching the set temperature, valve will close automatically to minimal 5% opening, which is the value set from the factory. It can be changed any time in Build-in valve 1 setup.

**Activation and setup of mixing valve 2 (for FH):**

- Activate Valve 2 (for FH) in Fitters menu, Build-in valve 2.
- Change the type of valve in Fitters menu, Build-in valve 2, Valve type, Floor valve. Maximal floor heating temperature is 55°C to protect the floor heating against higher temperatures.
- Set required valve 2 temperature in Fitters menu, Build-in valve, Valve temperature.
- Mixing valve will keep this temperature in the set level. In case of reaching the set temperature, valve will close automatically to minimal 5% opening, which is the value set from the factory. It can be changed any time in Build-in valve 2 setup.

You have connected room thermostats inside the connection board into selected outputs “Room regulator 1 or 2” or into “RS” output if you use RT10 room regulator.

- Standard room regulator activation: Activate standard (open/close) room regulator fo Valve 1 (for CH circuit) in Fitters menu, Build-in valve 1, Room regulator, “Standard room regulator”.
  - Set Valve 1 temperature decrease when no request for heating in Fitters menu, Build-in valve 1, Room regulator, “Change in se temperature”.
- RT10 room regulator activation: Activate RT10 room regulator fo Valve 1 (for CH circuit) in Fitters menu, Build-in valve 1, Room regulator, “RS regulator decrease”.
  - Set Valve 1 temperature decrease when no request for heating in Fitters menu, Build-in valve 1, Room regulator, “Room reg. temp. lower”.

- Standard room regulator activation: Activate standard (open/close) room regulator fo Valve 2 (for CH circuit) in Fitters menu, Build-in valve 2, Room regulator, “Standard room regulator”.
  - Set Valve 2 temperature decrease when no request for heating in Fitters menu, Build-in valve 2, Room regulator, “Change in se temperature”.
- RT10 room regulator activation: Activate RT10 room regulator fo Valve 2 (for CH circuit) in Fitters menu, Build-in valve 2, Room regulator, “RS regulator decrease”.
  - Set Valve 2 temperature decrease when no request for heating in Fitters menu, Build-in valve 2, Room regulator, “Room reg. temp. lower”.

- Equithermal operation (for CH and FH heating):**

- You can activate equithermal operation on both valves in Fitters menu, Build-in valve 1 or 2, “Weather control”.
- Keep I mind that Weather temperature sensor must be connected inside the connection board into the “Weather sens.” output.
- Set heating curve in Fitters menu, Build-in valve 1 or 2, Weather control, “Heating curve”.


The diagram illustrates a heating system configuration. A storage tank (PZ) is connected to a tankless water heater (DHW) and a radiator (CH). The system includes two pumps (P) and several valves. A dashed blue line represents a control loop involving a control unit (K) and a sensor (KR1). The system also features temperature (T) and pressure (P) sensors at various points.

## Basic connection with one circuit of central heating (operated by Valve pump 1) and one circuit of hot water (operated by DHW pump):

- Boiler protection against low-temperature corrosion by Build in mixing valve 1 (Fitters menu)
- Boiler control according to the set CH temperature (60°C or higher) and a DHW temperature (by customer's setup).
- All control elements and accessories are connected into the connection board, placed in front part of the boiler.
- Connect CH pump into the connection board (CH pump output).
- Connect DHW pump into the connection board (DHW pump output).
- Connect DHW sensor into the connection board (DHW sensor output).
- Check correct connection of CH sensor, which is inside the sink on the water outlet on the back side of the boiler. There should be no risk of losing the sensor and falling down out of the sink.
- Connect Mixing valve 1 pump into the connection board (Valve pump 1 output).
- Connect Valve 1 temperature sensor into the connection board (Valve 1 sensor output).
- Set maximal CH temperature in Main settings, CH temperature.
- Set maximal DHW temperature in Main settings, DHW temperature.
- Activate "Water heater priority" in Main settings, Working modes.
- Boiler will heat the domestic hot water tank as a priority according to the preset DHW temperature (DHW pump is turned on as a first until set DHW temperature is reached).
- Caution, DHW pump will be activated only if CH temperature is higher than actual DHW temperature to be sure that colder CH temperature isn't cooling down DHW tank.
- When set DHW temperature is reached, DHW pump is deactivated and CH pump is activated to maintain circulation of water inside heating system and to protect boiler overheating.
- CH or DHW pump will be activated only if measured CH temperature is 40°C or higher. Value set in service menu, "Pump switch on temperature".
- DHW pump will be activated again when DHW temperature drops by number set in Service menu, "DHW hysteresis". When DHW pump activated, CH pump is deactivated and the opposite.
- Connect room regulator into the connection board, into the "Room regulator 1 or 2" (standard open/close thermostat), or "RS" (RT10 thermostat) outputs. Depending on the type of thermostat you use.
- Activate room thermostat in fitters menu, Room regulator – "Standard room regulator" or "regulator OPOP". Depending on the type of thermostat you use.
- Set type of reaction on room regulator signal. Room thermostat can turn on/off the boiler immediately or it can decrease CH temperature by set level:
  - Immediate off/on boiler by room regulator:
    - Activate "Firing up function" in Fitters menu, Room regulator.
    - In case you want to deactivate CH pump in the same time as boiler by room regulator, activate "CH pump room regulator" function in Fitters menu, Room regulator. Be careful about the possibility of overheating when CH pump is deactivated!
  - Lowering set CH temperature by room regulator:
    - Deactivate "Firing up function" in Fitters menu, Room regulator.
    - Set level of CH temperature decrease when no request for heating from room regulator by "Room reg. temp. lower" in Fitters menu, Room regulator.
    - Set maximal CH temperature is now lowered by this value. So boiler will modulate power down sooner and it will also achieve maximal CH temperature sooner.
    - This type of regulation is recommended for bigger heating systems with lot of water volume inside. So boiler is not turned off by room thermostat too often and it takes less time to heat up the system again when room thermostat requires heating again.

Boiler will heat up DHW tank even in situation when room thermostat sends signal to stop heating. DHW production is not connected with room regulator's requests for heating.

## 10.4. One CH circuit (4-way mixing) + DHW (zone valve)



**Basic connection with one circuit of central heating (operated by Valve pump 1) and one circuit of hot water (operated by zone valve):**

- Boiler protection against low-temperature corrosion by Build in mixing valve 1 (Fitters menu)
- Boiler control according to the set CH temperature (60°C or higher) and a DHW temperature (by customer's setup).
- All control elements and accessories are connected into the connection board, placed in front part of the boiler.
- Connect CH pump into the connection board (CH pump output).
- Connect DHW zone valve into the connection board (DHW pump output).
- Connect DHW sensor into the connection board (DHW sensor output).
- Check correct connection of CH sensor, which is inside the sink on the water outlet on the back side of the boiler. There should be no risk of losing the sensor and falling down out of the sink.
- Connect Mixing valve 1 pump into the connection board (Valve pump 1 output).
- Connect Valve 1 temperature sensor into the connection board (Valve 1 sensor output).
- Set maximal CH temperature in Main settings, CH temperature.
- Set maximal DHW temperature in Main settings, DHW temperature.
- Activate "Parallel pumps" in Main settings, Working modes. Caution: With zone valve you have to always use Parallel pumps mode and you have to always use room regulator to switch off the boiler when no request for room heating.
- Boiler will heat the domestic hot water tank according to the preset DHW temperature (DHW pump is turned on as a first until set DHW temperature is reached).
- Caution, DHW pump will be activated only if CH temperature is higher than actual DHW temperature to be sure that colder CH temperature isn't cooling down DHW tank.
- When set DHW temperature is reached, DHW zone valve is closed but CH pump will maintain circulation of water inside heating system and to protect boiler against overheating.
- CH or DHW zone valve will be activated only if measured CH temperature is 40°C or higher. Value set in service menu, "Pump switch on temperature".
- DHW zone valve will be activated again when DHW temperature drops by number set in Service menu, "DHW hysteresis". When DHW zone valve activated, CH pump is continuing to work thanks to the "Parallel pumps" setup.
- Connect room regulator into the connection board, into the "Room regulator 1 or 2" (standard open/close thermostat), or "RS" (RT10 thermostat) outputs. Depending on the type of thermostat you use.
- Activate room thermostat in fitters menu, Room regulator – "Standard room regulator" or "regulator OPOP". Depending on the type of thermostat you use. Room thermostat activation is the same as in chapter 10.3.



*Keep in mind that introduced heating system diagrams are only one of many possibilities.  
Consider each specific heating system installation with your certified plumber.*

## 11. REGULAR MAINTENANCE



Regular maintenance is essential part of solid fuel boilers usage. Recommended intervals of regular cleaning of boiler, burner and flue path are listed below. Keep in mind that these intervals can vary and highly depend on pellet quality, combustion processes, level of dust inside the pellets, chimney draft and so on. So check how fast is ash created in boiler, burner and flue path regularly and set proper cleaning intervals for yourself.

	weekly	monthly	quarterly	yearly
Ashtray	•			
Burner grate	•			
Heat exchanger		•		
Control of combustion		•		
Fotosensor cleaning		•		
Door tightness check			•	
Full burner			•	
External feeder				•
Pellet hopper				•
Chimney flue path				•

### 11.1. Biopel 10 - 80kW

You can see main parts which should be cleaned in the right picture. Read all lines to see how cleaning is done, to be sure your boiler will be maintained properly during its long life.

- Cleaning the ashtray is an essential step during the regular maintenance of the boiler. Ensure correct placement of ashtray when putting back to the boiler.
- Burner grate is removable and requires regular cleaning. Watch the first few weeks of operation how often amount of ashes on the grate is created and regularly scrape it off with a cleaning tool. Perform this task only during inactivated state of the boiler (extinction).
- Carry out the cleaning in front of the boiler (around the burner) if necessary at the same time as cleaning the burner grate. Do not forget to close the cover flap above the burner after cleaning (inside Biopel 10-40kW).
- Cleaning flue gas turbulators and heat exchanger is an essential act. Ashes over the exchanger smoke coolers reduce efficiency and conversely increase the temperature of exhaust gas, thus, more heat escapes through the chimney, if the heat exchanger is dirty.  
Turbulators are removable. We recommend to regularly check the space between the turbulators and if necessary remove turbulators and clean.
- Once or twice a season check the flue path and clean it with help of a cleaning opening in the flue path.
- The burner should be occasionally removed from the boiler and completely cleansed. Burner maintenance procedures described in the next subsection.
- Once a season, check the tightness of all sealing cords on all doors. In case cords are hard and thus lost its sealing ability, we recommend replacing.



Generally, speed of ash creation inside the boiler and flue gas path depends on the quality of the combustion process, type and quality of pellets, the amount of dust in the pellets etc. Therefore, adjust the recommended cleaning intervals according to the actual situation during boiler operation.


Ash particles should be always small, if not check pellet type and combustion quality. There should be also no water inside the boiler, ashes should be totally dry.



### 11.2. Biopel 100 - 200kW

On the picture you can see the main parts of the boiler, which require manual maintenance at regular intervals. Below is a description of points that should not be overlooked during maintenance of the boiler.


- Biopel 100-200 kW does not include removable ashtray in its main internal space of the boiler. Ashes cleaned with cleaning tools (scraper) into an external container.
- Burner grate can be cleaned by opening the front door. Clean burner grate only when the boiler is deactivated, so at the moment when there is no flame inside the boiler.
- Heat exchanger is cleaned through opened doors and removed turbulators. Clean using a brush with a handle attached.
- The ash from the upper half of heat exchanger falls to small ash space (below the flue outlet) when cleaning. Place where there is a small removable ashtray inside. Check the amount of ash in the heat exchanger and the rear ashtray regularly.
- Once or twice a season check the flue path and clean it through a cleaning opening, which should be placed on the flue.
- The burner should be occasionally removed from the boiler and completely cleaned. Burner maintenance procedures described in the next subsection.
- Once a season, check the tightness of all sealing cords on all doors. In case cords are hard and thus lost its sealing ability, we recommend replacing.
- Once per season check connections for leaks at the cooling hoses, ball valves and water inlets and outlets.




### 11.3. Burner 10 - 200kW

On the picture you can see the main parts of the burner, which require manual maintenance at regular intervals. Cleanliness of burner is an essential factor in determining the quality of combustion.

- Burner grate is removable for easier access not only to the grate but also it. The space below the grate must be clean and also all openings in the grate are open.
- The burner grates with outputs from 10 to 30 kW are flat shape and its position is held by bottom plate on the grate. This bottom plate must fit under the front edge of the burner.
- Burner grates with outputs of 40-200 kW are square in and you must ensure that after placing the grate back to the burner you fix the grate by screw on the top of the burner. Otherwise grid can move out of the burner.
- For burners from 30 to 200 kW there is a grenamat brick placed above the grate, which serves to protect the upper part of the burner against overheating. Do not forget to place this brick back to the burner after cleaning.
- Regularly check the cleanliness of fotosensor by removing the burner pipe and clean the end of fotosensor napkin. Cleanliness of fotosensor is important for proper flame detection during the operating status of the boiler. Do not remove the fotosensor itself.
- Once a season, check the tightness of burner sealing cord. In case cord is hard and thus lost its sealing ability, we recommend replacing.



Burner grate 10-30kW




Burner without grate

Ask your installation company for thorough explanation of how to clean the boiler and burner so that the boiler is operated in accordance with those guidelines. Routinely clean boiler, burner and flue gas path to ensure maximum boiler efficiency and low fuel consumption during boiler operation.

Keep in mind that regular cleaning, good quality of combustion and type of the pellets are directly responsible for burner grate life. If you see some cracks or other types of damages on the grate, it is always due to one of mentioned factors. Combustion temperature when burning pellets is max 1200°C, which is no problem for stainless steel grate to handle if all mentioned advices are followed.

Next chapter talks about how to connect your Biopel to OPOP's online server and about how to keep you v9 control unit up to date.



Burner grate 40-200kW

## 12. BIOPEL ONLINE

Each Biopel boiler can be connected online to OPOP's online server. This connection is free for all Biopel users. This feature is ment for full heating system operation through internet browser or mobile phone. To connect to our online server follow simple steps below.

- Connect connection board and your internet signal receiver (modem or router) by Ethernet cable. Propojte Externí patiči s vaším přijímačem internetu (modem nebo router). You can find exact socket for internet connection in chapter *Electrical connections*.
- Registration code can be displayed inside v9 controller. You can do so in Fitters menu, Internet modul, Registration code. Display this code and note it for further use.
- Registration code is only 2 hours valid, so you should proceed to next steps of registration within 2 hours after displaying the code inside v9 controller.
- Open your internet browser on your computer or mobile phone and type in following address: [opop.emodul.eu](http://opop.emodul.eu)
- Click on "New user" button and make your registration. When all data filled, you created your login date to connect any time anywhere to your boiler. But before you can do that you have to register your boiler
- Log-in into the system using user name and password you just created during registration. When you are logged in, register your boiler.
- To do so, click on Settings on top right corner and than hit "New module" link.
- Fill all the data including also registration code which you saw inside v9 controller and save when all data filled properly.
- When modul registration completed, your boiler will be automatically connected into OPOP's online server. All data will be uploaded in few seconds on the server.

**!** *Ethernet cable must be connected and Ethernet module must be activated to receive live data of your boiler and heating system.*

From now on you can see and change all parameters of v9 controller online via PC or mobile phone. You can ask our representative or directly OPOP staff for more information about all possibilities of Biopel online features

## 13. FIRMWARE UPDATE

Each v9 controller can be updated by USB pendrive. OPOP is releasing firmware update regularly at least once a year. These updates can be downloaded for free from OPOP's websites or you can ask our representatives in your country to have your control unit up to date. Firmware update is very simple, follow steps below.

- Firmware update consists of one file, both for display and connection board. Save this file on your usb pendrive. Name of the file is „opopv9p.bin“.
- Turn off the boiler by main switch on the top of the connection board.
- Insert USB pendrive into the socket located directly on the v9 controller.
- Turn on main switch again.
- Wait until firmware update is finished. Controller unit displays standard main screen.
- Remove USB pendrive. Caution: do not remove USB pendrive before update is completed.
- V9 controller is up to date now.

Access Main settings, Software version to check which firmware version of V9 controller and connection board you currently use. To update properly you have to update always v9 control unit and connection board together using two files mentioned above.

Used USB key must be formatted in the FAT32 file system to properly upload files. To check what your USB key is formatted, right-click the icon for the USB key in your computer's operating system and enter Properties.

**!** **Caution: When you upload new software to the controller, default values are saved. It is therefore necessary to adjust all over again all the setup including First start setup.**

Always seek for advice from certified plumber or OPOP representative before uploading the firmware to make sure your boiler runs properly after firmware update. Next chapter is about all messages which can be displayed on the main screen. Use this list as a detailed explanatory list in case of alarm situation.

## 14. DOE AND ALARM MESSAGES

You can see full list of all alarm and other messages which could be displayed on the main screen. These should help you to deal with specific situations which can occur during boiler operation.

- 1. Alarm: Feeder sensor damaged**  
It is safety temperature sensor attached on the burner surface. Check sensor connection, small plug connection on burner PCB. Check also connection on the "Feeder sens." output inside the connection board.
- 2. Alarm: CH sensor damaged**  
CH sensor connected into the „CH sens.“ output inside connection board. Sensor is not functional or badly connected.
- 3. Alarm: DHW sensor damaged**  
DHW sensor connected into the „DHW sens.“ output inside the connection board. Sensor is not functional or badly connected. If you don't use DHW sensor check chapter *Electrical connections* to see which features are related to DHW sensor and deactivate these features to remove the alarm.
- 4. Alarm: Boiler overheated**  
Boiler CH temperature is higher than 93°C, which is value set in Service menu, Boiler alarm temperature.
- 5. Alarm: DHW temperature too high**  
DHW temperature measured by DHW sensor is higher than selected value in Main settings, DHW temperature.
- 6. Alarm: Termik opened**  
Termik sensor is not connected, damaged or measure CH temperature is higher than 95°C.
- 7. Alarm: Return sensor damaged**  
Return sensor is activated but not connected into the „Return sens.“ output inside the connection board. Or it is damaged. If you don't use Return sensor check chapter *Electrical connections* to see which features are related to Return sensor and deactivate these features to remove the alarm.
- 8. Alarm: C1-C4 sensor damaged**  
Temperature sensor is activated but not connected into the "C1-C4" outputs inside the connection board. If you don't use C1-C4 sensors check chapter *Electrical connections* to see which features are related to C1-C4 sensors and deactivate these features to remove the alarm.
- 9. Alarm: Valve sensor 1-2 damaged**  
Build-in valve 1 or 2 has been activated but Valve temperature sensor 1 or 2 is not connected into the „Valve 1, 2 sensor“ outputs inside the connection board. If you don't use Build-in valves deactivate these in Fitters menu, Build-in valve 1 or 2 to remove this alarm message.
- 10. Alarm: 3 ignitions per 30min**  
Boiler is igniting too often. Check the reason of this behavior. It could be poor flame detection by fotosensor, or bad combustion adjustments, or room regulator influence.
- 11. Message: No communication with RT10**  
RT10 room regulator is not properly connected. Check electrical connection and try to disconnect and connect again the RS data cable of RT10 regulator inside the connection board. If you don't use RT10 regulator deactivate it in Fitters menu, Room regulator to remove this message.
- 12. Message: No communication with Lambda**  
Lambda sensor is not connected and activated in Fitters menu, Lambda. Check lambda module connection into the RS data outputs inside the connection board.
- 13. Message: Temperature reached**  
Boiler is off by reaching CH temperature + Supervision temperature (in service manu). Example: CH temperature = 70°C, Supervision temperature = 5°C. Boiler is turned off when CH temperature is higher than 50+5 = 75°C, displaying "Temperature reached" message.
- 14. Message: DHW reached**  
Set DHW temperature is reached. DHW production will be started again when DHW temperature drops by value set in DHW hysteresis (in service manu).
- 15. Alarm: Damaged external sensor**  
Outside weather sensor is not connected into the „Weather sens.“ output inside the connection board. If you don't use Weather sensor check chapter *Electrical connections* to see which features are related to Weather sensor and deactivate these features to remove the alarm.
- 16. Alarm: Damaged Mosfet or Mosfet temperature too high or Incorrect fan**  
Mosfet component is responsible for fan speed modulation. Check service menu, Growth impulses feature.
- 17. Alarm: Feeder temperature too high**  
Intenal feeder temperature inside the burner is higher than 60°C. Value set n service menu, Max. feeder temperature.
- 18. Alarm: Firiing up failed**  
Two 12min long ignition phases have failed to create the flame or fotosensor doesn't detect the flame correctly.
- 19. Alarm: Temperature rise failed**  
CH temperature is not increasing fast enough. Check heating system and functions "Boiler alarm min temperture" and "Alarm time: temp. does not rise" in service menu.

## 15. SOLUTIONS TO SPECIFIC SITUATIONS

Following list is description all all common questions we get from our customers. They are usually about heating system installation or boiler operation. Read these carefully, informations listed below can help you to deal with specific situations that can occur during boiler usage.

### 1. Wrong flame at maximal burner power:

- a. Increasing the flame size: Service menu, Pellet settings, Operation parameters, Max power
  - i. Max feeding work – set higher value to make external feeder work for longer time
  - ii. Min feeding pause – set lower value to make external feeder pauses between work shorter
- b. Decreasing the flame size: Service menu, Pellet settings, Operation parameters, Max power
  - i. Max feeding work – set lower value to make external feeder work for shorter time
  - ii. Min feeding pause – set higher value to make external feeder pauses between work longer
- c. Decreasing the fan speed: Service menu, Pellet settings, Operation parameters, Max power
  - i. Max working fan – set lower number. Flame will be less aggressive and longer.
- d. Increasing the fan speed: Service menu, Pellet settings, Operation parameters, Max power
  - i. Max working fan – set higher number. Flame will be more aggressive and shorter.

***i** You can change flame size and agressivity by changing feeder work and fan speed. Wait 5min fter change to see real influence on the flame. Keep in mind that burner power must be at maximal 100% to see real influenc of your flame adjustments.*

### 2. Wrong flame at minimal burner power:

- a. How to reduce burner power at minimum:
  - i. Fitters menu, Coefficients, Forced minimal power

***i** By activating Forced minimal power, burner runs only at minimal output without power modulation. Wait 5min for flame to stabilize at minimal power and start to make corrections.*

- b. Increasing the flame size: Service menu, Pellet settings, Operation parameters, Min power
  - i. Min feeder operation – set higher value to make external feeder work for longer time
  - ii. Max feeding pause – set lower value to make external feeder pauses between work shorter
- c. Decreasing the flame size: Service menu, Pellet settings, Operation parameters, Min power
  - i. Min feeder operation – set lower value to make external feeder work for shorter time
  - ii. Max feeding pause – set higher value to make external feeder pauses between work longer
- d. Decreasing the fan speed: Service menu, Pellet settings, Operation parameters, Min power
  - i. Min working fan – set lower number. Flame will be less aggressive and longer.
- e. Increasing the fan speed: Service menu, Pellet settings, Operation parameters, Min power
  - i. Min working fan – set higher number. Flame will be more aggressive and shorter.

***i** Do not forget to deactivate “Forced minimal power” feature in Fitters menu, Coefficients otherwise boiler will run only at minimal power without any modulation.*

### 3. Unburned pellets inside the ashtray:

- a. Decreasing the fan speed: Service menu, Pellet settings, Operation parameters, Max power
  - i. Max working fan – set lower number. Flame will be less aggressive.
- b. Decreasing the fan speed: Service menu, Pellet settings, Operation parameters, Min power
  - i. Min working fan – set lower number. Flame will be less aggressive.
- c. Reduce external feeder work time: Service menu, Pellet settings, Operation parameters, Max power
  - i. Max feeding work – set higher value to make external feeder work for longer time
  - ii. Min feeding pause – set lower value to make external feeder pauses between work shorter

***i** Changing feeding pauses has always smaller influence that feeding work. Change feeding pause for small flame adjustments and feeding work for bigger flame influence.*

#### 4. Long or not successful ignition:

- a. High chimney draft – Chimney draft should be major factor to consider if ignition takes longer than 6 minutes. Higher draft than 15Pa negatively influences ignition and must be solved by installing chimney draft stabilisator. Standard ignition takes between 4 to 6 minutes.



*We highly recommend installing chimney draft stabilisator for each Biopel boiler in situation when chimney draft is higher than 15Pa.*

- b. Number of pellets on the grate: Service menu, Pellet settings, Ignition parameters
  - i. Underpore time – set higher or lower number. Pellets should cover the ignitor outlet under the grate, but too many pellets increase ignition time. Standard number is from 12 to 15s.
- c. Wrong fan speed: Service menu, Pellet settings, Ignition parameters
  - i. Fan speed 1/2 – set higher or lower number. Standard numbers should be from 4 to 15%.

#### 5. Fotosensor doesn't detect the flame:

- a. Fotosensor sensitivity: Service menu, Pellet settings, Ignition parameters
  - i. Firing up brightness – set lower number for higher sensitivity and the opposite. Standard number should be from 25 to 50. Keep in mind that lowering the number too much can cause room light detection so fotosensor sees the light even with no flame inside the boiler.
- b. Bad contact inside small green connector on the burner PCB board
  - i. If you see a "Feeder sensor damaged" alarm message on the main screen, always check the connection first to make sure small green socket is not damaged, no dust inside, etc.
- c. Fotosensor doesn't detect the light during or shortly after ignition
  - i. Flame after ignition is too small and fotosensor doesn't see it properly. Reduce number of "Max feeding pause" in Service menu, Pellet settings, Operation parameters, Min power. So the flame after ignition is big enough to be detected by fotosensor.

#### 6. Not successful firmware update:

- a. USB pendrive must be formatted in FAT32 data file format.
- b. Files are corrupted.



*Format your USB always before firmware update. If problem persists, try to use a different USB key.*

#### 7. No PID modulation:

- a. CH sensor or chimney sensor is not connected or measures incorrect values.
- b. Chimney temperature is higher than 170°C. Boiler is forced to run at reduced power output.
- c. PID modulation is influenced by real time measurement of CH temperature. Modulation depends on how fast is CH temperature increasing or decreasing so each heating system is different and modulation as well because of that.

#### 8. Lambda sensor is decreasing power:

- a. Change modulation range in Fitters menu, Lambda, Min and Max corrections. Factory settings are -15 and +15. It is necessary to reduce this range, set numbers closer to 0.
- b. Air leakage is influencing lambda sensor measurements. Check tightness of flue path, lambda sensor connection and also tightness of all doors.

#### 9. Lambda is making the combustion worse:

- a. Flame could be big and dark after lambda sensor activation (not enough air for good combustion). It means that Lambda sensor is probably measuring higher O<sub>2</sub> than set values and it is trying to reduce the fan speed to achieve requested O<sub>2</sub> values.
  - i. Check tightness of full flue path and especially connection where lambda sensor is inserted into the flue. Any additional air coming in to the boiler through non standard openings can highly influence proper O<sub>2</sub> measurements.
  - ii. You can also decrease modulation range to see if lambda stops to reduce oxygen too much. You can do it by Fitters menu, Lambda, Min and Max corrections, set number closer to 0.

#### **10. Data uploaded to OPOP online server are updated with long time delay:**

- a. Uploads are made periodically each minute of boiler operation.
- b. If the upload takes for example 10 or even more minutes to be visible on the screen, it means following factors are influencing upload time:
  - i. Check internet connection speed
  - ii. Check if some RS data output device (RT10 regulator, 431N module, GSM module or Lambda module) is activated inside Fitters menu but not connected into the connection board. Deactivate device which is not connected and upload speed should change to approx 1min depending on your internet speed.

#### **11. When alarm message deactivated it appears again**

- a. There is a fix limit for alarm detection, which is 15s.
  - i. First make sure that cause of the alarm has been eliminated.
  - ii. Second keep in mind that alarm can appear on the screen for one more time after eliminating the cause of it due to the alarm detection delay. When you confirm once more the alarm message by hitting ok button, it should never appear again.

#### **12. Not successful synchronisation**

- a. V9 control unit is synchronizing all data with connection board.
  - i. If the synchronisation fails, the reason is most probably incorrect data on your USB key. Keep in mind that both firmware files on your USB must be up to date.
  - ii. Be sure that you didn't have any type of alarm message on the screen when you started firmware update. First remove the cause of alarm, then make your firmware update.

#### **13. Too much ash on the grate:**

- a. Too many pellets on the grate. Reduce feeder work especially at maximal power.
- b. Low speed of the fan. Increase fan speed especially at maximal power.
- c. Wrong type of pellets. Pellets must be 100% made of wood only. Type of the wood is not important.
- d. High humidity of the pellets. Pellets burn only on the surface, don't create small particles of ashes.
- e. Wrong position of burner grate.
- f. Holes inside the grate are not empty.
- g. Lower than required chimney draft, minimum is 15Pa.
- h. Too much ash inside the boiler and flue path.
- i. Too much dust inside the pellets.

#### **14. High temperature inside the burner:**

- a. Burner temperature is displayed in left bottom part of the main screen.
- b. Standard value is up to 55°C.
  - i. Burner grate is not cleaned or you use bad pellets.
  - ii. Wrong burner grate position.
  - iii. Lower than required chimney draft, minimum is 15Pa.
  - iv. Too much ash inside the boiler and flue path.
  - v. Bad combustion adjustment – too many pellets or low fan speed.
- c. There is a risk of burner overheating ("Feeder temp. too high" alarm message). It is necessary to solve this issue immediately or you risk back flame and damage of burner and other parts of the boiler.

## 16. FACTORY SETTINGS

All factory settings are listed in tables below. These values are uploadet into the memory on v9 controller after finishing the First start procedure. Use these values as a reference when needed.

Ignition parameters:	10kW	15kW	20kW	30kW	40kW	60Kw	80Kw	100Kw	150Kw	200Kw
Blow-out time	30s	30s	30s	30s	30s	30s	30s	30s	30s	30s
Blow-by gear	100%	100%	100%	100%	100%	100%	100%	100%	100%	100%
Underpoor time	13s	13s	14s	14s	15s	15s	8s	8s	8s	8s
Friing-up delay	20s	20s	20s	20s	20s	20s	20s	20s	20s	20s
Feed time	3s	3s	3s	3s	3s	3s	3s	3s	3s	3s
Feed interval	120s	120s	120s	120s	120s	120s	120s	120s	120s	120s
Fan rotations	1%	1%	1%	8%	8%	8%	8%	8%	1%	1%
Fan rotations 2	3%	3%	3%	13%	13%	13%	13%	13%	3%	3%
Heater protection	12min	12min	12min	12min	12min	12min	12min	12min	12min	12min
Firiing-up brightness	38	38	38	38	38	38	38	38	38	38
Fan delay	30s	30s	30s	30s	30s	30s	30s	30s	30s	30s

Operation parameters:	10kW	15kW	20kW	30kW	40kW	60Kw	80Kw	100Kw	150Kw	200Kw
Min feeder operation	1	1	1	1	1	1	1	1	1	1
Max feeder work	1	1	2	2	3	3	2	3	3	4
Min feeding pause	11	9	14	11	10	9	10	11	9	9
Max feeding pause	24	24	19	19	17	17	17	16	15	14
Min working fan	5	5	5	17	18	18	18	20	20	20
Max working fan	9	10	13	36	37	38	38	40	45	48
Cleaning period	0h0min	0h0min	0h0min	0h0min	0h0min	0h0min	0h0min	0h0min	0h0min	0h0min
Operation controll	30s	30s	30s	30s	30s	30s	30s	30s	30s	30s

Damping parameters:	10kW	15kW	20kW	30kW	40kW	60Kw	80Kw	100Kw	150Kw	200Kw
Fan rotations	70%	70%	70%	70%	70%	70%	70%	70%	70%	70%
Feed time	5s	5s	5s	5s	5s	5s	5s	5s	5s	5s
Feed interval	20s	20s	20s	20s	20s	20s	20s	20s	20s	20s
Damping time	10min	10min	10min	10min	10min	10min	10min	10min	10min	10min
Delay time	5min	5min	5min	5min	5min	5min	10min	10min	10min	10min

Service menu:	10kW	15kW	20kW	30kW	40kW	60Kw	80Kw	100Kw	150Kw	200Kw
Max temp. exhaust	220°C	220°C	220°C	220°C	220°C	220°C	220°C	220°C	220°C	220°C
Feeder alarm temperature	53°C	53°C	53°C	53°C	53°C	53°C	53°C	48°C	48°C	48°C
Priority temperature	75°C	75°C	75°C	75°C	75°C	75°C	75°C	75°C	75°C	75°C
CH pump emergency activation	85°C	85°C	85°C	85°C	85°C	85°C	85°C	85°C	85°C	85°C
Boiler larm temperature	93°C	93°C	93°C	93°C	93°C	93°C	93°C	93°C	93°C	93°C
Internal feeder coefficient	100%	100%	100%	100%	100%	100%	100%	100%	100%	100%
Min. boiler temperature	40°C	40°C	40°C	40°C	40°C	40°C	40°C	40°C	40°C	40°C
Pump switch on temperature	40°C	40°C	40°C	40°C	40°C	40°C	40°C	40°C	40°C	40°C
Growth impulses	0	0	0	0	0	0	0	0	0	0
Suppervision temperature	5°C	5°C	5°C	5°C	5°C	5°C	5°C	5°C	5°C	5°C
Boiler hysteresis	15°C	15°C	15°C	15°C	15°C	15°C	15°C	15°C	15°C	15°C
DHW hysteresis	10°C	10°C	10°C	10°C	10°C	10°C	10°C	10°C	10°C	10°C

Main settings, Burner cleaning:	10kW	15kW	20kW	30kW	40kW	60Kw	80Kw	100Kw	150Kw	200Kw
On	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Cleaning period	15min	15min	15min	10min	10min	10min	10min	10min	10min	10min
Fan operation time	10s	10s	10s	10s	10s	10s	10s	10s	10s	10s
Blow force	60%	60%	60%	80%	100%	100%	100%	100%	100%	100%

Fitters manu, Lambda:	10kW	15kW	20kW	30kW	40kW	60Kw	80Kw	100Kw	150Kw	200Kw
First of time update	10min	10min	10min	10min	10min	10min	10min	10min	10min	10min
Time of update	300s	300s	300s	300s	300s	300s	300s	300s	300s	300s
Oxygen surge	2%	2%	2%	2%	2%	2%	2%	2%	2%	2%
Fan stroke	2%	2%	2%	2%	2%	2%	2%	2%	2%	2%
Sum	Ano	Ano	Ano	Ano	Ano	Ano	Ano	Ano	Ano	Ano
Min correction	15%	15%	15%	10%	10%	10%	10%	10%	10%	10%
Max correction	15%	15%	15%	10%	10%	10%	10%	10%	10%	10%
Lambda 100%	11%	10%	9%	11%	11%	9%	7%	7%	6%	6%
Lambda 1%	12%	12%	13%	14%	15%	12%	10%	12%	12%	12%

<b>Fitters menu, Compressor 1 &amp; 2 &amp; 3 :</b>	<b>10kW</b>	<b>15kW</b>	<b>20kW</b>	<b>30kW</b>	<b>40kW</b>	<b>60Kw</b>	<b>80Kw</b>	<b>100Kw</b>	<b>150Kw</b>	<b>200Kw</b>
Cleaning period	1min	1min	1min	2min	2min	2min	2min	3min	3min	3min
Opening time	2s	2s	2s	2s	2s	2s	2s	2s	2s	2s
Cycle time	17s	17s	17s	25s	25s	25s	25s	25s	25s	25s
Pause time	4h	4h	4h	4h	4h	4h	4h	4h	4h	4h

<b>Fitters menu, Vacuum:</b>	<b>10kW</b>	<b>15kW</b>	<b>20kW</b>	<b>30kW</b>	<b>40kW</b>	<b>60Kw</b>	<b>80Kw</b>	<b>100Kw</b>	<b>150Kw</b>	<b>200Kw</b>
Operation time	30min	30min	30min	30min	30min	30min	30min	30min	30min	30min
Switch on time	9:00	9:00	9:00	9:00	9:00	9:00	9:00	9:00	9:00	9:00
Swith on time 2	15:00	15:00	15:00	15:00	15:00	15:00	15:00	15:00	15:00	15:00
Opening time	80s	80s	80s	80s	80s	80s	80s	80s	80s	80s
Pause time	20s	20s	20s	20s	20s	20s	20s	20s	20s	20s

<b>Fitters menu, Ash removal:</b>	<b>10kW</b>	<b>15kW</b>	<b>20kW</b>	<b>30kW</b>	<b>40kW</b>	<b>60Kw</b>	<b>80Kw</b>	<b>100Kw</b>	<b>150Kw</b>	<b>200Kw</b>
Operation time	5min	5min	5min	10min	10min	10min	10min	10min	10min	10min
Pause time	10h	10h	10h	10h	10h	10h	10h	10h	10h	10h

These vales can be changed only by certified plumber who has been trained to install OPOP boilers.

Vales shown inside the tables can be use for better navigation through boiler setup and start up.

Changing these parameters can highly influence boiler operation. In case of emergency you can always use factory values from this table to be sure boiler runs properly in most of the cases. If you reset values in each main submenus by hitting Factory settings button, you change all your setup to values listed in this table.



## 17. WARRANTY CONDITIONS, GENERAL INFORMATION

All requirements below must be fulfilled by installer and end user to fulfill warranty conditions and also to ensure correct installation in terms of the applicable standards, and safety from the perspective of ensuring the non-problematic usage of the boiler and all other equipment.

1. Biopel boilers can be installed only by a company with a valid authorization to perform its installation and maintenance.
2. Installation project must be elaborated in accordance with applicable regulations.
3. The heating system must be filled with water, which meets the requirements of ČSN 07 7401 and especially its hardness must not exceed the required parameters. Using antifreeze fluids is not recommended by the manufacturer.
4. Connecting the boiler to the system must be done in accordance with applicable regulations and standards.
5. The flue gas path must be checked by chimney-sweeper before commissioning of the boiler. Require an audit report covering the basic parameters of the flue gas path, including the diameter of the chimney, its length and chimney draft.
6. Flue should not be longer than one meter (distance between the boiler and chimney inlet) and should be fitted with a cleaning opening. The flue can be extended only if the chimney draft was measured and recorded no longer than 30 cm from the boiler outlet and it meets the minimum operating draft, see chapter *Main parameters*.
7. Biopel boiler must be installed in a separate boiler room, specially adapted for heating. The boiler room must have sufficient space for installation and maintenance of the boiler. There must be sufficient circulation of fresh air for combustion. The boiler must never be installed in open spaces or balconies, in areas inhabited by people. Such as kitchen, living room, bathroom, bedroom, also in areas where there are explosive and flammable materials.
8. It is recommended to install the boiler on a concrete base from fire-proof material. There should be guaranteed minimum handling area around boiler and pellet hopper. 60cm rear and lateral sides, 100cm from the front of the boiler and hopper.
9. When installing and operating the boiler it is necessary to keep a safe distance of 200 mm from flammable materials.
10. It is disallowed to store fuel behind the boiler or next to the boiler within a distance smaller than 800 mm.
11. It is interdicted to store the fuel between two boilers in the boiler room.
12. We recommend to keep the distance between the boiler and fuel min. 1000 mm or store the fuel in a different room.
13. Guarantee fuel types are considered pellets made only of wood, their diameters ranging from 6-8 mm.
14. Boiler manufacturer is responsible for fuel quality in terms of combustion quality, the amount of ash, intervals for cleaning. These facts only affect the external factors such as the quality of pellets, dust and moisture in the pellets, chimney draft and correct setting of the combustion process.
15. To ignite pellets it is forbidden to use flammable liquids (gasoline, alcohol, etc.).
16. During the boiler operation it is forbidden to overheat it. Maximal CH temperature should be 85°C.
17. If there is a danger of development and penetration of combustible vapors or gases into the boiler room, or during works with temporarily developed fire or explosion danger (gluing the floorings, painting with combustible paints etc.), boiler must be put out of operation.
18. Upon completion of the heating season, it is necessary to clean the boiler including flue. The boiler room must be kept clean and dry.
19. It is forbidden to interfere with construction and electrical installation of the boiler.
20. Manufacturer is not liable for damage caused by improper adjustments or setup or improper handling of the product.
21. Wear parts are not covered by the standard warranty period. These parts are: sealing cord, grenamat bricks, ignitor, lambda sensor. These parts, however, perform for a long time if the boiler and its components are operated in accordance with the instruction manual.
22. The manufacturer is not responsible for rust on the boiler and its components, since it is always and only caused by external influences, as the humidity in the room, in the fuel or due to improper installation without boiler protection against low-temperature corrosion.
23. Boiler must be protected against low return temperature via a valve, which prevents the cold water going back to the boiler. Minimum acceptable return water temperature is set by the manufacturer at 55 ° C.
24. The manufacturer is not responsible for the condensation of cold air in the flue path, since this must be prevented by proper installation of flue gas path and by the correct setting of the combustion processes.
25. The manufacturer is not responsible for the leakage of smoke from the boiler into the room in case that this is caused due to low chimney draft, incorrect installation of the boiler, or incorrect setting of the combustion process.
26. The manufacturer is not liable for damage caused by handling, shipments, incorrect settings or improper use or other external factors, which are not directly caused by the individual components operation.
27. Installing company that sold the boiler to the end customer is always responsible for proper installation, boiler setup and activation.
28. In the event, it was agreed to maintain the warranty conditions by a third party subject (eg. startup company), then it must be so agreed on three sides, by sales representative, installer and the end customer. All mentioned subjects must agree with this and must be included with signatures in the appendix of warranty card.

## 18. STANDARDS AND REGULATIONS

These standards must be met during boiler installation and usage. Informations below are meant for installers as a support files for installation and boiler start up.

### Heating system:

The heating system must be filled with water that meets requirements of ČSN 07 7401 and especially its hardness must not exceed the required parameters: hardness = 1mmol/l, Ca<sup>2+</sup> = 0,3mmol/l, concentration of total Fe+Mn = 0,3mg/l.

ČSN 06 0310	Heating systems in buildings - Design and installation
ČSN 06 0830	Heating systems in buildings - Safety devices
ČSN 07 7401	Water and steam for thermal energy equipments with working steam pressure up to 8 MPa.
ČSN EN 303-5	Boilers for central heating – Part 5: Heating boilers for solid fuel, with manual or automatic fuel supply, nominal heat output up to 500 kW – Terminology, requirements, testing and marking.

### Flue gas system:

ČSN 73 4201	Designing chimneys and flues.
-------------	-------------------------------

### Fire regulations:

ČSN 06 1008	Fire safety of heat installations.
ČSN EN 13 501-1+A1	Fire classification of construction products and buildings - Part 1: Classification using test data from reaction to fire.

### Electricity network:

ČSN 33 0165	Electrical regulations. Marking the conductors with colors or digits. Implementing regulations.
ČSN 33 1500	Electrical regulations. Revision of electrical devices.
ČSN 33 2000-3	Electrical regulations. Electrical equipment. Part 3: Setting the basic characteristics.
ČSN 33 2000-4-41	Electrical devices: part 4: Safety chap. 41: Protection against electric shock.
ČSN 33 2000-5-51	Electrical regulations. Construction of electrical equipment.
ČSN 33 2130	Electrical regulations. Internal wiring.
ČSN 33 2180	Electrical regulations. Connection of electrical devices and appliances.
ČSN 34 0350	Electrical regulations. Regulations for mobile connections and wiring management.
ČSN EN 60 079-10	Electrical regulations. Regulations for electrical equipment in areas with potentially explosive flammable gases and vapors.
ČSN EN 60 079-14 ed.2	Electrical apparatus for explosive gas atmospheres - Part 14: Electrical installations in hazardous areas (other than mines).
ČSN EN 60 252-1	Capacitors for AC motors - Part 1: General - Performance, testing and rating - Safety requirements - Guide for installation and operation.
ČSN EN 60 335-1 ed.2	Electric appliances for household and similar purposes - Safety - Part 1: General requirements.
ČSN EN 60 335-2-10	Electric appliances for household and similar purposes Safety - Part 2-102: Particular requirements for appliances burning gas, oil and solid fuel having electrical connections.
ČSN EN 60 445 ed. 3	Basic and safety principles for man – machine interface, marking and identification.
ČSN EN 60 446	Basic and safety principles of machinery operation - Marking the conductors with colors or digits.

ČSN EN 61000 – 6 – 3 EMC – Part 6 – 3: Generic standards – Emissions - residential, commercial and light industry.

ČSN EN 61000 -3 – 2 EMC - Part 3 – 2: Bound – Limits for harmonic current emissions (equipment input current up to 16 A inclusive).

ČSN EN 61000 – 3 –3 EMC – Part 3 - Bound - chapter 3: Limitation of voltage fluctuation and flicker in low-voltage supply systems for equipment with rated current <16A.

### System for DHW:

ČSN 06 0320	Heating systems in buildings - Hot water preparation - Designing and planning.
ČSN 06 0830	Heating systems in buildings - Safety devices.
ČSN 73 6660	Water supply systems

### Placement options:

ČSN 06 1008	Combustibility grade B, C1, C2 and C3.
ČSN EN 13 501-1	Building materials and products classified in the flammability degree
ČSN 33 2000-3	The basic environment for handling space around the boiler AA5 / AB5.

## 19. WARRANTY CARD

### Biopel line v9 premium

**Producer:** OPOP spol. s r.o., Valašské Meziříčí, Česká republika  
**Tel.:** 00420 571 675 589, **fax.:** 00420 571 611 225

#### Instructions for complaint procedure:

This warranty certificate includes a certificate of quality and completeness. The manufacturer certifies that the product is inspected and meets its design specifications and EN 303-5. For quality and function we guarantee the boiler for 24 months from the date of sale to the consumer, no longer than 30 months after expedition from the factory and in a way that demonstrably result of defects due to faulty materials, faulty design, faulty design or removed as soon as at our expense, provided that the boiler:

- it is in normal condition according to the Instruction manual
- boiler and all additional devices are installed and operated in accordance with standards and laws in given State
- is connected to a chimney according to CSN 73 4201:1989
- is not damaged mechanically (no unauthorized interference)
- chimney draught must match the value listed in chapter 3 *Main parameters*, according to the type of boiler
- consumer complaints submitted with the application of this warranty certificate fully completed
- complying with the manufacturer's instructions for the use of pressure expansion vessels
- all conditions mentioned in chapter 17 *Warranty conditions* must be met

#### Note:

When a fault occurs, it is always necessary to submit the warranty certificate, give the exact address and the circumstances under which the defect occurred. The manner and place of repair will be decided in our company.

#### Extended warranty:

Standard 24 months warranty period can be extended up to 60 months for boiler body weldment if following list is filled each year to extend warranty period for one additional year. Warranty extension list must be filled by certified plumber to extend the warranty from 2 to 3 years and so on up to 5 years.

**Date and stamp of manufacturer:**  
(production date)

**Date and stamp of plumber:**  
(plumbing company, which realized sale of boiler)

## Warranty extension

Customer's name: \_\_\_\_\_

Boiler name: \_\_\_\_\_

Address: \_\_\_\_\_

Serial number: \_\_\_\_\_

City: \_\_\_\_\_

Installation date: \_\_\_\_\_

Answer all questions below by YES or NO or parameter value each year. Fill additional information if necessary. At the end fill date when this inspection was made.

text color is for visual inspection

text color means inspection during boiler operation

Question:	First startup	Year +1	Year +2	Year +3	If NO, write a reason
Is the boiler operated at maximum operating pressure up to 2 bar?					
Is it used a safety valve up to 2.0 bar max?					
Is it the return water temperature in boiler operation at least 55°C?					
Is it used 3 or 4-way valve for boiler protection against low-temp. corrosion?					
Is boiler installed by a certificated company?					Company name:
Is the boiler operated under the conditions specified in the user manual?					
Is boiler and burner clean?					
Is boiler dry inside?					
Is annual service performed each year?					
Is it the installation of all temperature sensors in accordance with installation manual?					
Does customer use only guarantee fuel?					
Is the combustion and flame parameters correct?					
Min. feeder operation					
Max. feeder work					
Max feeding pause					
Min feeding pause					
Min working fan					
Max working fan					

Extended warranty? (yes/no)				
-----------------------------	--	--	--	--

Date of inspection				
--------------------	--	--	--	--

Service company: \_\_\_\_\_

Year +1

Year +2

Year +3

Use this form along with a warranty list in the event of complaint procedure in extended warranty time period.

OPOP, spol. s r. o.

Zašovská 750

757 01 Valašské Meziříčí

Bank account:

Komerční banka a.s., č. účtu: 1608851/0100

IČO: 47674105, DIČ: CZ 47674105

Telephone: sales: 571 675 589, secretariat: 571 611 250, production: 571 675 405

supply: 571 675 114, finance: 571 675 472

---